

GFK-1918

[Buy GE Fanuc Series 90-30 NOW!](#)

GE Fanuc Manual Series 90-30

CIMPLICITY Machine Edition Logic Developer-PLC
Getting Started

1-800-360-6802
sales@pdfsupply.com

Getting Started

Logic Developer - PLC PLC Programming Software

Version 3.00

June 2002

GFK-1918C



All rights reserved. No part of this publication may be reproduced in any form or by any electronic or mechanical means, including photocopying and recording, without permission in writing from GE Fanuc Automation North America, Inc..

Disclaimer of Warranties and Liability

The information contained in this manual is believed to be accurate and reliable. However, GE Fanuc Automation North America, Inc. assumes no responsibilities for any errors, omissions or inaccuracies whatsoever. Without limiting the foregoing, GE Fanuc Automation North America, Inc. disclaims any and all warranties, expressed or implied, including the warranty of merchantability and fitness for a particular purpose, with respect to the information contained in this manual and the equipment or software described herein. The entire risk as to the quality and performance of such information, equipment and software, is upon the buyer or user. GE Fanuc Automation North America, Inc. shall not be liable for any damages, including special or consequential damages, arising out of the use of such information, equipment and software, even if GE Fanuc Automation North America, Inc. has been advised in advance of the possibility of such damages. The use of the information contained in the manual and the software described herein is subject to GE Fanuc Automation North America, Inc. standard license agreement, which must be executed by the buyer or user before the use of such information, equipment or software.

Notice

GE Fanuc Automation North America, Inc. reserves the right to make improvements to the products described in this publication at any time and without notice.

© 2001, 2002 GE Fanuc Automation North America, Inc. All rights reserved. CIMPPLICITY is a registered trademark of GE Fanuc Automation. Any other trademarks referenced herein are used solely for purposes of identifying compatibility with the products of GE Fanuc Automation North America, Inc..

We want to hear from you. If you have any comments, questions, or suggestions about our documentation, send them to the following email address:

doc@gefanuc.com

Contents

1	Welcome	1
	System Requirements	.3
	Installation	.4
	Product Authorization	.5
	Technical Support	.7
2	CIMPLICITY Machine Edition	9
	Quick Start	.10
	Projects	.12
	Global search	.13
	Tools	.14
	Variables	.16
	Machine Edition Help	.18
	Companion Help	.18
	InfoViewer Help	.18
3	GE Fanuc PLC Targets	21
	Creating and Configuring Targets	.22
	Creating Targets	.22
	Configuring Targets	.22
	Configuring Communication	.24
	Interacting with the PLC	.27
	Validating a Target	.27
	Upload/Download	.27
	Run/Stop	.29
	Online/Offline	.30
	Fault Tables	.30
	Reference View Tables	.31
	Reports	.33
4	HWC Hardware Configuration	35
	Configuring Series 90™-30 PLC Hardware	.35

DSM314 Motion Module	38
Series 90™-70 PLC Redundancy	40
Configuring Redundant Systems	42
VersaMax Remote I/O	46
Series 90™-70 Genius Remote I/O Scanner	49

5 Logic Editors 51

LD Editor	53
Working with the LD Editor Offline	54
Working with the LD Editor Online	57
Word-for-Word Changes	58
Writing Changes to a Target PLC	59
LD Functions	60
IL Editor	64
Working with the IL Editor Offline	65
Working with the IL Editor Online	67
Writing Changes to a Target PLC	68
IL Instructions and Functions	69
C Blocks	71
Working with C blocks	71
C Programs	73
User Programs	73
Working with User Programs	74

6 Motion Programming 77

PLC Motion Editor	78
Working with the Motion Editor	79
Motion Commands	80
Local Logic	81
Working with Local Logic Editor	82
Local Logic Variables	83
Local Logic Commands and Operators	85
CAM Editor	86
Working with the CAM Editor	87

1


Welcome

Congratulations on your purchase of Logic Developer - PLC, the GE Fanuc PLC programming component of Machine Edition automation software. This software package provides all the tools necessary to create powerful control applications.

Logic Developer - PLC provides a way to configure your PLC hardware or remote I/O, create and edit PLC logic, upload and download projects, and monitor and debug the execution of control programs. Projects can be imported from Logicmaster, VersaPro, and CimplicityControl folders.

Logic Developer - PLC makes it possible to develop control applications on a personal computer and download them to a PLC via Ethernet or serial/modem connection.

CIMPLICITY Logic Developer - PLC Environment



Hosted in the Machine Edition environment, Logic Developer - PLC takes advantage of a powerful set of common programming tools (see page 14). The same tools can be applied to Logic Developer - PC (PC Control), Logic Developer - State, View and Motion components, providing a single programming environment. The Machine Edition environment unites and organizes components, providing data sharing and networked operation.

The following features are included in this version of Logic Developer - PLC:

- **Hardware Configuration (HWC):** a comprehensive tool for configuring and customizing GE Fanuc PLCs or racks of Remote I/O for your specific operating needs. For more information on Hardware Configuration, see page 37.
- **LD Editor:** an intelligent, cell-based, graphical editor for developing LD (Ladder Diagram) logic. You can customize the look and feel of the LD Editor. For more information on the LD Editor, see page 51.
- **IL Editor:** an easy-to-use, free-form text editor for creating Instruction List Logic. Configurable formatting rules and color coding make your scripts easy to read. For more information on the IL editor, see page 64.
- **PLC Motion Editor:** a free-form text editor that enables you to enter the program in your preferred style. The PLC Motion editor is specifically designed for support of the DSM314 motion module. For more information on the Motion editor, see page 77.
- **Local Logic Editor:** a text-based editor used for developing logic that executes locally on a DSM314 motion module. Local Logic runs synchronously with the PLC Motion program, but is independent of the PLC's CPU. For more information on the Local Logic editor, see page 83.
- **CAM Editor:** an accessory for the Logic Developer - PLC motion editor specifically designed for support of the DSM314 motion module. It provides a graphical means to create, edit, and manage electronic CAM profiles. For more information on the CAM editor, see page 86.
- **C Blocks and C Programs:** independent sections of executable code, written in C language, that are developed outside of Logic Developer - PLC, using GE Fanuc's *C Programmer's Toolkit for Series 90 PLCs User's Manual* (GFK-0646). Precompiled C blocks and C programs (.exe files) are imported into your project. For more information on C blocks, see page 71. For more information on C programs, see page 73.

SYSTEM REQUIREMENTS

- Windows® NT version 4.0 with service pack 4.0 or later

OR

Windows 2000 Professional

OR

Windows XP

OR

Windows 98 SE.

- Internet Explorer version 5.5 with Service Pack 2 or later. (You must install IE5.5 SP2 before installing Machine Edition.)
- 200 MHz Pentium-based computer. (300 MHz if the operating system is Windows XP or Windows 2000.)
- 128 MB RAM.
- TCP/IP Network protocol-based computer.
- 110 MB free hard disk space (and up to 310 MB if other CIMPLICITY Machine Edition products are concurrently installed).
- 200 MB hard disk space for sample projects (optional).
- Additional hard disk space for projects and temporary files.

INSTALLATION

To install Logic Developer - PLC

1. Insert the CIMPLICITY Machine Edition CD into your CD-ROM drive.
By default, the setup program will automatically start. If the setup program does not automatically start, run *Setup.exe* in the root directory of the CD.
2. Click **Install** to start the install process.
3. Follow the instructions as they appear on the screen.

PRODUCT AUTHORIZATION

Before you can start developing projects with Logic Developer - PLC, you must authorize the software with a program called Product Authorization. If you don't authorize the software, you can use it for only a four-day trial period. This procedure takes only a few minutes and enables you to take advantage of any product support for which you qualify. You will need to contact us by telephone, fax, or e-mail as part of the authorization process.

To authorize a copy of Machine Edition

1. **Have your serial numbers ready.**
The serial numbers can be found on the License Key sheet that came with your product.
2. **Run the Product Authorization program from the Start menu > Programs > Product Authorization.**
The Product Authorization dialog box appears.
3. **Click Add.**
4. **Select the medium with which you are authorizing: Internet, Phone/Fax/E-mail, or Floppy Disk Transfer. Click Next.**
If you choose the Internet option, proceed to step 5.
If you choose the Phone/ Fax/E-mail option, proceed to step 5.
If you choose the Floppy Disk Transfer option, ensure you have an authorization disk before proceeding.
5. **Fill in the fields in the dialog box.**
Fields that are identified with an asterisk (*) must be filled in.
6. **If authorizing by:**
 - **Internet**, click **Submit Authorization**. We will reply by e-mail with your new key code(s).
 - **Phone**, click **Phone/Fax** and call the number on the screen to receive a new key code(s).
 - **Fax**, click **Phone/Fax**. In the dialog box that appears, click **Print FAX**. Fax the Product Authorization Request to us, using our fax number on the printout. We will reply by fax with your new key code(s).
 - **E-mail**, click **Send E-mail**. In the dialog box that appears, click **Authorize** to e-mail us. We will reply by e-mail with your new key code(s).

Product Authorization is complete after you enter the new key code and it has been accepted. Depending on the product you have purchased, you may need to run the Product Authorization program a number of times.

To move the authorization to another computer

You can run the software on only the computer that the Product Authorization was run on. If you want to develop your projects on a different computer, you need to complete the following steps to move the authorization from one computer to another.

1. **Install Logic Developer - PLC on the computer that the authorization will be moved to. Run the Product Authorization program from the **Start menu > Programs > CIMPLICITY Machine Edition > Product Authorization.****
The Product Authorization dialog box appears.
2. **Click **Software.****
There is a Target Site Code on the top right-hand side of the screen. Write down this site code carefully. It must be accurate for the move to work. You will need the Target Site Code when you move the authorized software from the source computer.
3. **Click **Add.****
The Product Authorization wizard appears.
4. **Click **Authorize by disk.****
At this point, you need to go to the source computer that has the authorized software, and move the authorization to a disk.
5. **From the source computer, run the Product Authorization program and click **Software.****
6. **Click **Move,** and then click **OK.** Enter the Target Site Code that you wrote down from Step 3 and click **Next.** Verify that the site code is correct and click **OK.****
7. **Insert a blank formatted floppy disk into the floppy drive and click **Next.****
The authorization code will be moved to the disk and a dialog box should appear telling you it was successful.
8. **Click **OK.****
9. **Go back to the computer to which you are moving the authorization and insert the floppy disk.**
The screen that is asking for an authorization disk should be displayed.
10. **Click **Next.****
11. **Click **Finish.****
A screen should appear telling you the move was successful.
12. **Click **OK.****
The authorization has now been moved to the new computer.

TECHNICAL SUPPORT

Support is available to registered users at no charge for 90 days after purchase. A *Support and Free Enhancements (SaFE)* subscription can be purchased from your local GE Fanuc distributor if extended support is required.

If problems arise that can't be solved using the information in your product manual, online Help system, or the GE Fanuc Technical Advisor knowledge base, contact us by telephone, fax, or mail.

When contacting us, call from a telephone near your computer and have your CIMPLICITY Machine Edition software running. Have the following information handy to help us assist you as quickly as possible:

- The serial number from your installation CD case, and the Product name and version number from the **Help>About** dialog box.
- The brand and model of any hardware in your system.
- Operating system and version number.
- The steps you performed prior to the problem occurring.

North America

Support Hotline: 1-800-GEFANUC (1-800-433-2682)

Fax: (780) 420-2049

Internet: <http://www.gefanuc.com>

Email: support@gefanuc.com

Comments about our manuals and help: doc@gefanuc.com

Mailing Address: GE Fanuc
2700 Oxford Tower, 10235 - 101 St.
Edmonton, AB, Canada, T5J 3G1

South America

Telephone: +58 (261) 760 2862

Fax: +58 (261) 765 0909

Internet: <http://www.gefanuc.com> (visit our Portuguese web site at www.gefanuc.com.br)

E-Mail: luis.wilhelm@gefanuc.com

Mailing Address: GE Fanuc Automation Latin America
Calle 120 con Av. 17, Los Haticos -GE Turbimeca
Maracaibo, Venezuela

Europe

Internet: For up-to-date contact information, visit www.gefanuc-europe.com and click on "Offices and Services".

For up-to-date technical information visit www.gefanuc.com/support.

E-mail: plc_europe@gefanuceur.ge.com


2

CIMPLICITY Machine Edition

Machine Edition offers you a complete solution for the development of automation applications in one package. Machine Edition features an integrated development environment and tools which allow you to spend more time building applications and less time learning the software. All Machine Edition products are fully integrated into the environment and interact with each other.

- They share a common project database. No more wasted time synchronizing data points between applications.
- They share the same set of tools providing a consistent interface throughout the development process.
- They feature full drag-and-drop capabilities between tools and editors.
- They feature a true scalable solution. You have the choice of what type of machine your projects run on.
- They automatically display Help in the Companion for what you click on.

The following illustrates a Machine Edition project:




QUICK START

Machine Edition makes it easy to get started developing a project.

To start Machine Edition

1. Click  **Start**, point to **Programs**, point to **CIMPLICITY Machine Edition** and then choose **CIMPLICITY Machine Edition**.

After Machine Edition initializes, the Environment Themes dialog box appears.




Note: The Environment Themes dialog box appears automatically the first time you start Machine Edition. To change the theme later, choose **Apply Theme** from the Windows menu.

2. Choose the environment theme you want to work in.
3. Click **OK**.

When you open a project, the appearance of your Machine Edition screen will match the preview in the Environment Themes dialog box.

The CIMPLICITY Machine Edition dialog box appears.



4. Select the appropriate option to open a project. The **Open an existing project** option is selected by default.

Notes:

- If you select either the **Empty project** option or the **Machine Edition template** option, the New Project dialog box appears and you can continue creating a new project (see page 12).
 - If you select the **Open an existing project** option, you can also select either the **Recent Projects** option or the **All Projects** option. The **Recent Project** option is selected by default.
5. If you selected the **Open an existing project** option, select from the list the project that you want to open.
The existing projects include samples and tutorials that you can open and use to familiarize yourself with Machine Edition.
 6. If you want, select the **Don't show this dialog box on startup** option.
 7. Click **OK**.

Your project opens in the Machine Edition environment that you specified in the Environment Themes dialog box.

PROJECTS

You can create and edit Machine Edition projects using products such as View, Logic Developer - PC, Motion Developer, Logic Developer - State, and Logic Developer - PLC. These products share Machine Edition tools to provide a high level of integration between the various parts of your project.

Folders created with Logicmaster, CimplicityControl, or VersaPro can be imported.

Using Logic Developer - PLC, you can build a number of different projects to suit your specific requirements.


To create a new project using a template

Before creating a project, there are some things you should know:

- The primary components your project will contain.
- The PLC you project will run on.

1. From the File menu, choose New Project, or click  on the File toolbar.


The New Project dialog box appears.





2. Choose a Project Template that suits your needs.
3. Enter a descriptive Project Name.
4. Click **OK**.

Your project opens in the Machine Edition environment.

To open an existing project for editing




Navigator: Manager tab

1. Open the  Navigator and choose the  Manager tab.

A list of projects is displayed.


2. Right-click a project and choose **Open**.

Your project loads and is ready for editing.

 **Want to know more?** In the Help Index, look up "Projects".


To import a folder

1. Open the Navigator and choose the Project tab.
2. Select the target that you want to import the folder into.
3. Right-click the target, point to **Import**, and choose the folder type.
4. In the dialog box that appears, navigate to and select the folder to import, and click **OK**.

 **Want to know more?** In the Help Index, look up "import a CimplicityControl folder", "import a Logicmaster folder", or "import a VersaPro folder".

GLOBAL SEARCH


Logic Developer - PLC provides the capability to search for some text in an entire target or portions thereof, which you can specify. Various options are available to further narrow a search.

 **Want to know more?** In the Help Index, look up "Global" and select the "Conducting a Global Search" help topic.

TOOLS

Project development is supported by the Machine Edition tools. Each tool is opened and closed by means of a button on the Tools toolbar.

A description of each tool's function is outlined below.



Navigator

The Navigator is a docking tool window containing a set of tabs. Each tab displays information about your development system in a hierarchical tree structure similar to Windows Explorer. The available tabs depend on which Machine Edition products you have installed and what kind of work you are developing or managing. The Project tab shows the overall organization of your application.



Feedback Zone

The Feedback Zone window is a docking window used to display several types of output information generated by Machine Edition –enabled components. This interactive window uses category tabs to organize the output generated from the Machine Edition products you have installed.



Inspector

The Inspector lists the properties and current settings for a selected object or element. You can edit these properties directly in the Inspector. When you select several objects, the Inspector window lists the properties common to all of them. The Inspector window provides a simple method of viewing and setting properties for all objects.



Data Watch

The Data Watch tool is a runtime debugging tool that enables you to monitor and edit the values of variables. This tool is useful while working online to a target. With the Data Watch tool, you can monitor individual variables or user-defined lists of variables. Data Watch lists can be imported, exported, or saved with a project.

Toolchest

The Toolchest is a powerful storehouse of objects you can add to your project. You can drag most items directly from the toolchest into Machine Edition editors. You can choose from predefined objects or create your own reusable fxClasses. The Toolchest adds true object oriented capability to Machine Edition.

Companion

The Companion provides useful tips and information while you work. While the Companion is open, it tracks your moves and displays help on whatever item is currently selected in the Machine Edition environment. It is context-sensitive and displays a description of whatever you click on the Machine Edition screen.

InfoViewer

Machine Edition online help system is an integrated display engine and Web browser. If you are familiar with Internet Explorer or Netscape Navigator, then you are already familiar with the basic InfoViewer interface. Like the Companion, the InfoViewer is context-sensitive. Simply press F1 to get help on any item you select in the Machine Edition environment. A table of contents is found in the InfoView tab of the Navigator.

 **Want to know more?** In the Help Index, look up "Tools: an Overview".

VARIABLES


A variable (sometimes called a tag) is a named storage space for data values.

All variables in a project are presented in the Variables tab of the Navigator. A variable represents a memory location in the target PLC. Each variable is mapped to a reference address (for example, %R00001). The reference address and other properties of a variable, such as data type, are configured in the Inspector.

Arrays and compound structure variables are supported by Machine Edition.

Variable definitions can be imported from and exported to a variety of file types.


You can edit your variables in a spreadsheet and then import them. The following picture shows the Inspector displaying a typical set of variable properties.



Navigator: Variables tab

Variable [MyTargetName]	
Name	myBOOL
Description	
Publish	True
Array Dimension 1	0
Data Source	GE FANUC PLC
Ref Address	%I00001
Data Type	BOOL
Current Value	Off
Initial Value	Off
Default Display Format	On / Off
Retentive	True
Force State	Not Forced
General	

To create a variable



New Variable menu

1. In the Variables tab of the Navigator, right-click **Variable List**, point to **New Variable** and then choose the data type of the variable.

A new variable with a default name appears in the list.

2. **Type a name for the variable and press ENTER.**

Variable names can range from 1 to 32 characters, begin with a letter, contain upper or lower case letters, use numbers between zero and nine, and use the underscore character (“_”).

To map a variable to PLC memory

In order to successfully download a project to the PLC, variables must be properly mapped to the PLC's memory. There are two ways to map a variable.

First method:

1. In the  Variables tab of the  Navigator, right-click a variable and choose Properties.

The Inspector opens showing the properties of the variable.

2. In the Ref Address field, enter an address. You can:
 - Spell out the exact address, for example, %R00123 or 123R. In either case this maps the variable to %R00123.
 - Enter only the memory area, for example %R. This maps the variable to the next highest available address. For example, if %R00122 was the last address used, entering %R maps the variable to %R00123.

Second method:


1. In the  Variables tab of the  Navigator, right-click a variable and choose Properties.

The Inspector opens showing the properties of the variable.

2. Click the  button in the Ref Address field.




The Reference Address Wizard appears.



3. From the Memory Area list, choose a region of PLC memory.
4. In the Index box, enter an index from the beginning of the region.
5. Click **OK**.

Your variable is mapped to the Reference Address.

 **Want to know more?** In the Help Index, look up "Variables" and "Importing variables from a file".

MACHINE EDITION HELP


CIMPLICITY Machine Edition includes a comprehensive online help system that enables you to access specific help topics while working with Machine Edition.

Use the InfoViewer or Companion to access help.


Companion Help

The Companion is a Machine Edition help system that provides useful tips and information while you work. While the Companion is open, it displays help on whatever item is currently selected in the Machine Edition environment, tracking your movements while you work.

To use Companion help

1. Ensure the  Companion window is open. To open it, press Shift+F11.
2. Click on any item on the screen.

A description of the item you clicked appears in the Companion.




InfoViewer Help

The InfoViewer, another Machine Edition help system, provides detailed information. The InfoViewer has its own toolbar for navigating the help system, a Table of Contents (in the InfoView tab of the Navigator), and a searchable index. As with the Companion, InfoViewer help is context-sensitive. Click an item on the screen and press F1 to display the appropriate topic in the InfoViewer.

To use the Help index

1. From the Help menu, choose Index.

The Index dialog box appears.




2. Enter or choose a keyword from the list.
3. Click **List Topics**.

A list of topics appears. The topics are sorted by their rating or likelihood of containing the correct information.

4. Select a topic to display.
5. Click **Display**.

The selected Help topic is displayed in the InfoViewer.

To look up topics in the Help Table of Contents




Navigator: InfoView Tab

1. Open the InfoView tab of the Navigator.

A table of contents for the entire help system appears.


2. Expand Libraries and Books to locate a topic of interest
3. Double-click a topic.

The topic is displayed in the InfoViewer.




3

GE Fanuc PLC Targets



Navigator: New 90-30 Project

A  target represents a runtime destination of the programs you develop with Logic Developer - PLC. Each target contains all of the components that will download to it. Logic Developer - PLC supports the following GE Fanuc PLC targets:

- Series 90™-30 PLC
- Series 90™ Micro PLC
- VersaMax® PLC
- VersaMax® Nano/Micro PLC
- Series 90™-70 PLC

and the following remote I/O interface targets:


- GE Fanuc VersaMax Ethernet
- GE Fanuc VersaMax Profibus
- GE Fanuc VersaMax Genius
- GE Fanuc Series 90™-70 Genius Remote I/O Scanner

CREATING AND CONFIGURING TARGETS

Creating Targets

Normally a target is present in a project when you use a template to create the project (see page 12). A project can contain any number of targets. One target is required for each PLC or remote I/O adapter your project accesses.

To add a target to a project



Project right-click menu

1. In the Project tab of the Navigator, right-click the Project node and point to **Add Target**.
2. Point to **GE Fanuc PLC** or **GE Fanuc Remote I/O** and then choose the PLC family.

Configuring Targets


The properties of a target specify the PLC family, the communication connections between your computer and the PLC, and various other settings. All properties are edited in the Inspector. The following table describes these target properties:


Name	Edit the name for your target in this field.
Type	The type of target is set by default to GE Fanuc PLC. Note: Logic Developer - PLC is only operational with GE Fanuc PLCs.
Description	Enter a brief description of your project in this field.
Documentation Address	Enter the URL where your project documentation is stored.
Family	Change the PLC type in this field. Caution: Changes are irreversible.
Program Name	The name of the target known to the PLC.
Update Rate (ms)	Set the rate at which the screen is updated while online.
Sweep Time (ms)	The sweep time of the PLC when online is also displayed on the status bar.
PLC Status	The online/offline, run/stop status of the PLC.
Dual HWC	(Series 90™-70 only) Indicates whether HWC redundancy is set up. Change the field to False to delete the secondary HWC.
Selected HWC	(Displayed only if Dual HWC is set to True) Change the selected HWC in this field.
Physical Port	Choose the type of connection to the PLC (Ethernet COM or modem).
IP Address	Set the IP address of the PLC (Ethernet protocol only).
Additional Configuration	Group of properties used for the detailed configuration of your communication connection.

To change the PLC family

1. In the  Project tab of the  Navigator, right-click an existing  target and choose Properties.

The properties of the target appear in the Inspector.

2. In the Inspector,  click Family.
3. From the list, choose the PLC family type.







Warning: Changing the PLC Family can result in logic in your project becoming invalid.

Note: PLC hardware must be configured before it will be operational. For detailed information on hardware configuration, see page 37.


Configuring Communication

In order for Logic Developer - PLC to communicate with a target PLC, a connection must be properly configured. The properties of a target are adjustable to accommodate your connection(s).

To configure an Ethernet or serial connection




1. In the  Project tab of the  Navigator, right-click a  target and choose **Properties**.
The Inspector opens showing the target's properties.
2. In the  Inspector, set the Physical Port property to Ethernet or a COM port (or a modem if one is installed).
3. If the Physical Port is Ethernet, enter the IP Address of the target PLC.
4. Double-click Additional Configuration to access the detailed settings for your connection.

Note: Serial communication with a PLC is always available if it is the only device connected and an SNP_ID is not specified. An IP address must be set in the PLC before an Ethernet link can be established.

 **Want to know more?** In the Help Index, look up "Connections".

To set an IP address for a Series 90™-30 CPU364 or CPU374


Note: For CPU364 and higher-end Series 90™-30 CPUs, the Ethernet connection is built into the CPU. For lower-end Series 90™-30 CPUs, the Ethernet connects through an optional expansion slot on the rack.

1. Obtain an IP address, perhaps from your network administrator.
2. In the  Project tab of the  Navigator, expand the  Hardware Configuration node to reveal the rack and slot containing a CPU364 or CPU374.
3. Right-click the slot containing the CPU364 or CPU374 and choose **Configure**.

The Parameter editor appears.


4. In the Parameter editor, click the Ethernet tab.

The Parameter editor displays the contents of the Ethernet tab.



5. Double-click the IP address field.

The IP Address dialog box appears.



6. Enter the IP address in the box and click **Ok**.

To set an IP address for lower-end Series 90™-30 CPUs

1. In the Project tab of the Navigator, expand the Hardware Configuration node.
2. Right-click the slot containing an Ethernet Communication Module and choose Configure.

The Parameter editor opens showing the configuration settings for the module.

3. In the Settings tab, double-click the IP Address field.


The IP Address dialog box appears.

4. Enter the IP address and click **OK**.

To set an IP address for Series 90™-70 PLCs

1. In the Project tab of the Navigator, expand the Hardware Configuration node.
2. Expand the Main Rack and right-click the slot where you want to add a communications module.

The Module Catalog appears.



3. Choose the **Communications** tab and select the communications module you want to add.
Select either IC697CMM741 or IC697CMM742.
4. Click **OK**.
The Parameter editor opens showing the configuration settings for the module.
5. In the **Settings** tab, double-click the **IP Address** field.
The IP Address dialog box appears.
6. Enter the IP Address and click **OK**.

To download an IP address to a PLC

1. Configure a CPU or Ethernet COM Module with an I/P address using Hardware Configuration.
2. Connect to the PLC via serial connection.
Note: Do not specify an SNP_ID.
3. Download the Hardware Configuration to the PLC.
The IP address is assigned to the PLC.
4. Connect to the PLC via Ethernet connection.

INTERACTING WITH THE PLC




Communicating with the PLC is necessary to perform such operations as storing and loading programs or monitoring data values and PLC status information. You can connect to a PLC from Logic Developer - PLC over a serial, Ethernet or modem connection, depending on the capabilities of the PLC.


All interactions with a target are available from the target's right-click menu.

Validating a Target

Validating your project detects any syntax errors that may be present. Error messages are generated for each error and displayed in the Feedback Zone. A project containing errors cannot be downloaded. For that reason, whenever you initiate a download, the logic is automatically validated.

To validate a target

- In the  Project tab of the  Navigator, right-click a  target and choose **Validate**.

Logic Developer - PLC checks all items under the target for syntax errors. Any errors detected are noted with messages in the Build tab of the  Feedback Zone.



Tip: Double-click an error message to locate the noted error in your project. The appropriate editor or tool opens automatically with the item in question selected. Tips showing you how to proceed are displayed in the Companion.

Upload/Download


The download process creates (or builds) and validates all runtime files necessary for a target to perform its role in a completed project. The compiled project is then transferred to the target hardware via the communication connection previously configured.

The upload process acquires a project from an active PLC target and transfers it to Logic Developer - PLC for editing.

To download to a target PLC

1. In the  Project tab of the  Navigator, right-click the  target to which you want to download files and choose **Download to PLC**.

The Selections dialog box appears.





Note: If the PLC is running, you can only download logic that is not equal to the PLC's current logic and the Selections dialog box does not appear.

2. Choose the items you want to download and click **OK**.

Tip: To download files for all targets in a project, right-click the project node and choose **Download All**. If you want to download files to the active target, choose **Download Active Target**.

Note: Only one project can be downloaded to a target at a time. If you download to a target machine that already has a project on it, the existing project is overwritten.


For each target that you download to, Machine Edition saves the project, performs a validation, builds the runtime files and attempts to establish a connection to the target. Any errors that occur are displayed in the Build tab of the  Feedback Zone. If connection to a target is successful, Machine Edition sends all the necessary runtime files to the PLC.

 **Want to know more?** In the Help Index, look up "Downloading".

To upload files from a PLC

1. In the  Project tab of the  Navigator, right-click the  target PLC from which you want to upload information and choose **Upload from PLC**.

The Upload from PLC dialog box appears.



Note: If you are uploading from Logic Developer - State, only the Hardware Configuration can be uploaded.

2. Choose the item(s) you want to upload and click **OK**.

Logic Developer - PLC connects to the PLC and uploads the selected item(s) to Logic Developer - PLC. If you already had a version of the PLC's project open, the uploaded project merges with the existing project. This ensures that all variable names are retained throughout the uploading process. If you upload to any empty target, all variables are assigned default names. For example, %R00001 is named R00001.

Run/Stop


You can set a target PLC to Run or Stop mode. In Run mode, you can choose to have outputs enabled or disabled. In Stop mode, you can choose to enable or disable the outputs.

- In the  Project tab of the  Navigator, right-click a  target, point to **Online Commands** or to **Offline Commands**, and then choose **Start PLC**.

The target PLC begins executing its program.

1. In the  Project tab of the  Navigator, right-click a  target, point to **Online Commands** or to **Offline Commands**, and choose **Stop PLC**.

The Stop PLC dialog box appears, prompting you to enable or disable the PLC's outputs.



Target: Right-click menu

Offline commands

2. Select an option.




The target PLC stops executing its program.

3. Click OK.


Online/Offline




When offline from a target PLC, the number and type of interactions available are limited. You can upload, download, or start, stop, or clear the PLC. You can also verify the equality of the PLC's program to your open project. However, while online to a target PLC, you can interact with the target in real-time and monitor the operation of the PLC using the DataWatch, Reference View and Fault tables. Also, while online, the LD editor displays a graphical representation of LD logic as it executes, if the PLC's project is equal to the current project. You can edit LD logic while online; you are prompted to download your word-for-word changes.

To go online to a PLC

- In the  Project tab of the  Navigator, right-click a  target PLC and choose **Go Online**.

Logic Developer - PLC connects your project to the PLC. The online status is indicated by the target icon in the Project tab and on the status bar.



Note: When online to a PLC, the target icon in the Project tab of the Navigator appears as  (equal),  (not equal), or  (faulted).

To go offline from a PLC

- In the  Project tab of the  Navigator, right-click a  target PLC and choose **Go Offline**.

Logic Developer - PLC goes offline.

Fault Tables

The PLC and I/O Fault Tables display fault information logged by the CPU or modules in the PLC. This information is used to determine if there are problems with the PLC hardware or software running in the PLC's CPU. To view the PLC and I/O fault tables, your computer must be online to the PLC.

To view the fault table reports

- In the Project tab of the Navigator, right-click the target you want to report on and choose **Diagnostics**.

The fault table appears in the InfoViewer window.

Choose the type of fault information you require.

Print fault table by clicking here.

Select the format of fault data.

Sort fault information.

Clear fault information by clicking here.

Indicates online status of PLC.

View the date and time of the faults.

Double-click a row to view details of faults.

PLC Date/Time: 05-27-2000 01:51:16
Last Cleared: 01-01-2000 00:59:59

Fault Table Viewer Status
Online

PLC Fault Table (Displaying 16 of 23 faults, 7 Overflowed)

Loc (rack:slot)	Fault Description	Date/Time
0.1	No user program present	01-01-2000 01:07:09
0.1	No user program present	01-01-2000 01:27:52
0.1	No user program present	01-01-2000 01:41:54
0.4	LAN system-software fault; resuming	01-01-2000 01:41:54
0.4	LAN transceiver fault; OFF network until fixed	01-01-2000 01:41:54
0.4	LAN system-software fault; resuming	01-01-2000 01:43:55
0.4	LAN transceiver fault; OFF network until fixed	01-01-2000 01:43:55
...	Error Code Group Action Task Num	
...	454 14 2:Diagnostic 0	
Fault Extra Data: 0c 01 02 00		
0.1	No user program present	01-02-2000 20:51:08
0.0	Rack size mismatch	01-18-2000 01:58:12
0.0	Rack size mismatch	01-20-2000 20:55:15
...	Error Code Group Action Task Num	
...	1 14 2:Diagnostic 126	
Fault Extra Data: 00		
0.0	Rack size mismatch	01-20-2000 21:19:19

Reference View Tables

Reference View Tables (RVTs) contain a user-defined list of reference addresses that can be monitored and changed in real-time. A target can have zero or more user-defined RVTs, included in the Reference View Tables folder in the Project tab of the Navigator.

The number of entries contained in an RVT does not affect performance. Performance is affected only by the number of entries that are displayed and have to be updated in the view.

An RVT displays data when the parent GE Fanuc PLC target is active and online.

You can configure the appearance of your RVTs in the Options tab of the Navigator.

Data values at sequential addresses are displayed, by default, from right to left, starting at the reference address specified. The amount of data displayed in the eight columns depends on the data display format.

The screenshot shows a software window titled 'InfoViewer' with a table of data. A context menu is open over the table, showing various display formats. The table has columns for data values and an 'Address' column. The data is displayed from right to left, starting from the 'Starting Address'.

Format of selected address	Selected address	Starting Address
Signed Decimal	%M00001	Address
+0, +0	+0, -8170, +100, +12720	%R00001
00, 00000000	00, 00000000, 00000000, 00000011	%Q00001
00, 00000000	00, 00000000, 00000000, 00000001	%I00001
+0, +0	+0, +0, -32, -16, -16, +1488	%A10001
+0, +0	+0, +0, +0, +0, +0, +1610	%AQ0001
00, 00000000	00, 00000000, 00000000, 00000001	%M00001
	000000, 00010110, 01011010	%S00001

Subsequent addresses are displayed right to left.


This is the data at the starting address.

Display format can be selected for individual cells or the entire table.

To create a Reference View Table

- In the Project tab of the Navigator, right-click on the Reference View Tables folder and choose **New**. A new Reference View Table with a default name is added to the folder.

Working with a Reference View Table



Navigator: Project Tab

Reference View Table node

1. In the Project tab of the Navigator, expand the Reference View Tables folder and double-click the table you want to view.

The Reference View Table appears.

2. Add reference addresses to the table as required.
3. Format the table entries as desired.

Want to know more? In the Help Index, look up "RVT".

Reports

Reports provide summaries and tables of information about your project. Most reports are generated and displayed in the InfoViewer window. The Reports tab of the Feedback Zone contains a list of all reports generated since the last Machine Edition project was opened. The following list shows the types of reports and logic printouts available in Logic Developer - PLC:

Address Use report	C block report*
Hardware Configuration report	IL block report*
Variables report(s)	Local Logic block report *
CAM profile report	Motion block report*

Notes


- An asterisk (*) indicates a logic printout.
- Reports are not generated for LD blocks. Rather, these blocks are printed directly from the LD editor.


To create reports

- In the Project tab of the Navigator, right-click a node and choose Report to generate a report on that node.

A report is automatically generated and displayed in the InfoViewer.

To redisplay a previously generated report

1. In the  Feedback Zone, double-click the Reports tab.

A list of previously generated reports appears in the  Feedback Zone.

2. Choose, from the list, the report you want to view.

The report displays in the Infoviewer.

Many items in a report contain hyperlinks. Click a hyperlinked item to jump to that item in the project. For example, if a variable's name appears hyperlinked in a report, clicking it selects that variable in the Variables tab of the Navigator.

Large reports are often separated into several pages. To view a different page of the report, scroll to the bottom of the report in the InfoViewer and click the number of the page you want to view.


To print a report appearing in the InfoViewer


1. Do one of the following:

Generate the report you want to print.

or


Redisplay a previously generated report.

2. When the report is displayed, right-click the  InfoViewer window and select **Print**.

 **Want to know more?** In the Help Index, look up "Reports".

4

HWC Hardware Configuration



Navigator: Project Tab

HWC node


Logic Developer - PLC supports five GE Fanuc PLC families and various remote I/O interfaces (see page 46) with a variety of CPUs, racks and modules for each. In order to operate, PLC hardware must be configured with Logic Developer - PLC or some other GE Fanuc tool. The HWC component of Logic Developer - PLC provides a way to completely configure your target equipment. This chapter details specifics on configuring PLC hardware for your operational needs.

The first step in configuring PLC hardware is to select the PLC you want to configure (see page 22). When creating a new project, either you use a project template containing default hardware configuration, or you create an empty project and configure it manually.

Configuring Series 90™-30 PLC Hardware

One of the most popular GE Fanuc PLCs in use today is the Series 90™-30, the configuration of which is detailed in the following procedures. Procedures for the other PLC types supported by Logic Developer - PLC are almost identical.

By default, each Series 90™-30 target is configured with eight racks: a main rack and seven secondary racks. Each rack has either five or ten slots; the first slot in the main rack is always reserved for the CPU. The following diagram shows a typical 10-slot Series 90™-30 PLC.








To choose a CPU


Open Parameter Editor	Enter
Cut	Ctrl+X
Copy	Ctrl+C
Paste	Ctrl+V
Add Module...	Ins
Replace Module...	
Delete Module	Del
Properties	Alt+Enter

HWC right-click menu

The default CPU specified in all project templates for a Series 90-30 is the CPU364. To change the CPU:

1. In the  Project tab of the  Navigator, expand the  Hardware Configuration folder.
All racks are revealed.
2. Expand the  Main rack.
3. Right-click  Slot 1 and choose **Replace Module**.

The Module Catalog dialog box appears.



4. From the list, select a CPU.
5. Click **OK**.

You are prompted to confirm the replacement.

6. Click **Yes**.

A dialog box appears asking you if you want to retain the settings from the existing CPU.


7. Click **Yes** or **No**.

The target is configured with the selected CPU.

To configure a CPU


1. In the  Project tab of the  Navigator, right-click a slot containing a CPU and choose **Configure**.

The Parameter editor appears showing all configurable settings for the CPU.






2. Modify settings as required. For further information, see your PLC manual.


To select a rack type



Navigator: Project tab
HWC configuration

1. In the  Project tab of the  Navigator, right-click a  rack node and choose **Replace Rack**.



The Module Catalog dialog box appears listing available rack types.




2. Select a rack and click **OK**.

To choose a power supply

The default power supply for the Series 90™-30 is the PWR321. To change the power supply:

1. In the  Project tab of the  Navigator, right-click the PWR slot and choose Replace Module.

A list of optional power supplies appears.



2. Select the power supply you have installed in your rack and click OK.

DSM314 Motion Module

The Motion Mate DSM314 (see page 77) is a high performance, easy-to-use multi-axis motion control module. Compatible with 90-30 PLC logic solving and communications functions, the DSM314 supports the following servo types:


- Digital - GE Fanuc digital servo amplifiers and motors.
- Analog - GE Fanuc SL Series analog servos and third-party servos are supported.

The DSM314 Motion module has four axes that can be individually configured in Standard or Follower mode. It can control up to four analog mode servo axes or up to two digital mode servo axes. When axis one and two are controlling digital mode servos, axis three can control an analog servo.

In order to perform motion programming in Logic Developer - PLC, you must have a DSM314 motion module properly configured (see page 77).

Note: The Motion Mate DSM314 is compatible with only Series 90™-30 PLCs.

To add a DSM-314 motion module


1. With a rack of the  Hardware Configuration node expanded, right-click the empty slot you want to add a DSM314 motion module to and choose **Add Module**.

The Module Catalog dialog box appears.

2. On the Module Catalog dialog box, click the Motion tab.

A selection of motion modules appears in the Module Catalog dialog box.

3. From the list, select Motion Mate DSM314.



4. Click OK.

A DSM314 is added to the hardware configuration of your project.

To configure a DSM314


1. In the Project tab of the Navigator, double-click the slot containing a Motion Mate DSM314.

The Parameter editor appears.

Parameters	Values
<i>Number of Axes:</i>	4
%I Reference:	%I00001
%I Length:	80
%Q Reference:	%Q00001
%Q Length:	80
%AI Reference:	%AI0001
%AI Length:	84
%AQ Reference:	%AQ0001
%AQ Length:	12
<i>Axis 1 Mode:</i>	Analog Servo
<i>Axis 2 Mode:</i>	Analog Servo
<i>Axis 3 Mode:</i>	Auxiliary Axis
<i>Axis 4 Mode:</i>	Disabled
<i>Local Logic Mode:</i>	Disabled
Total Encoder Power (Watts):	0

2. Configure the DSM314 using the Parameter editor.

Note: For details on configuring the DSM314, see *GFK-1742, Motion Mate DSM314 for Series 90-30 PLCs Users Manual*.



Navigation: Project Tab
HWC Node
Redundant HWC

Series 90™-70 PLC Redundancy

In redundant systems, two PLCs are set up and configured to share the responsibility of a single PLC. If one unit fails or is taken offline the other unit assumes responsibility without interrupting operation of the entire system.

Redundancy is used with Series 90™-70 PLCs. A target is associated with two physical PLCs, a Primary and a Secondary. Both PLCs share the same logic, but each has its own Hardware Configuration (HWC): Primary or Secondary. The selected HWC is the HWC that you can go online with, download to, upload from, and so on.

There are three types of redundant systems:

- Basic CPU Redundancy
- Genius Redundancy
- CPU Redundancy Over Genius

Basic CPU Redundancy

Three types of basic CPU redundancy are supported for Series 90™-70 rack systems. These redundant systems can be used in combination with Genius redundancy schemes.

- Single Bus with Preferred Master - uses a single Genius bus with one or more bus controllers in each PLC. The primary unit is always chosen as the active unit when the units initially synchronize.
- Single Bus with Floating Master - uses a single Genius bus with one or more bus controllers in each PLC. No switchover occurs on initial synchronization to make the primary unit the active unit.
- Dual Bus with Floating Master - uses dual busses with one or more bus controllers in each PLC. No switchover occurs on initial synchronization. Bus Switching Modules (BSMs) are required in accordance with configuration of a dual bus network. This option provides redundancy of both the PLC and the I/O bus.

Genius Redundancy

A redundant Genius system contains duplicate components that are controlled in a way that keeps the Genius system operating properly even if one of the duplicate components fails or is taken out of service. Redundant Genius systems can be used in combination with Series 90™-70 redundant CPU systems.

Five types of redundant Genius systems can be configured.

- Genius Dual Bus Redundancy (Paired GBC Internal)
- Genius Dual Bus Redundancy (Paired GBC External)
- Genius Dual GBC Redundancy (Paired GBC Internal)
- Genius Dual GBC Redundancy (Paired GBC External)
- Genius Dual Bus & Dual GBC Redundancy

CPU Redundancy Over Genius

A CPU Redundancy Over Genius System contains duplicate components that are controlled in a way that keeps the system operating properly if one of the duplicate components fails or is taken out of service.

Five types of CPU Redundancy Over Genius system can be built upon the various types of redundant Genius systems combined with the basic CPU Redundancy schemes.





- CPU Redundancy (GHS) Using Genius Dual GBC Redundancy (Paired GBC External) - Single Bus with Preferred Master
- CPU Redundancy (GDB) using Genius Dual GBC Redundancy (Paired GBC External) - Single Bus with Floating Master
- CPU Redundancy (GDB) using Genius Dual Bus Redundancy (Paired GBC External) - Single Bus with Floating Master
- CPU Redundancy (GDB) using Genius Dual Bus and Dual GBC Redundancy - Dual Bus with Floating Master
- CPU Redundancy (GDB) using a Mixed Genius Redundancy Scheme


? **Want to know more?** In the Help Index, look up “Redundant HWC: an Overview”.

Configuring Redundant Systems


The procedures below are the general steps to follow for configuring redundant systems. See the online help for the procedures on configuring specific redundancy systems.

To set up the primary hardware configuration for CPU redundancy

1. In the  Project tab of the  Navigator, expand the  target node for which you want to set up CPU redundancy.
2. Right-click  Hardware Configuration, point to **Redundancy**, and choose **Wizard**.



The Redundancy Wizards dialog box opens, with the *Set up a Primary Hardware Configuration for CPU Redundancy* option selected by default.



- Click **Next** and follow the wizard to the end. The wizard adds a redundant CPU, the Bus Transmitter Module (BTM) and the Redundancy Communications Module (RCM) to the configuration.

Note: The target property, *Dual HWC*, is now available in the Inspector and is set to False.


Target	
Name	Target1
Type	GE Fanuc PLC
Description	
Documentation Address	
Family	Series 90-70 PLC
Program Name	Target1
Update Rate (ms)	250
Sweep Time (ms)	Offline
PLC Status	Offline
Dual HWC	False
Physical Port	COM1
Additional Configuration	

Inspector

Adding Genius Bus Controllers (GBC) to your system

- In the  Project tab of the  Navigator, expand the  target for which you want to set up CPU redundancy.
- Right-click  Hardware Configuration, point to **Redundancy**, and choose **Wizard**.




The Redundancy Wizards dialog box appears.




3. Select **Add GBCs for Genius Redundancy**.
4. Click **Next** and follow the wizard to the end. The wizard allows you to select a Genius redundancy scheme and the location of the GBC modules. You can run this wizard multiple times to configure additional pairs of redundant busses in the same system.

Note: When you add a Genius Bus Controller (GBC) to a Series 90™-70 rack, a new Genius bus network is automatically created and associated with that slot and GBC module. Up to 31 Genius I/O devices (blocks) can be connected to a GBC through its Genius bus.

Configuring the secondary hardware configuration


1. In the  Project tab of the  Navigator, select the  Hardware Configuration folder.
2. Right-click Hardware Configuration, point to **Redundancy**, and choose **Mirror to Secondary Hardware Configuration**.




A secondary rack system that is a copy of the primary rack system is generated. The target now displays two Hardware Configurations (HWCs), respectively labeled [Primary] and [Secondary]. The Primary HWC is bolded because it is currently selected. The target property, *Dual HWC*, is now set to True.

Target	
Name	Target1
Type	GE Fanuc PLC
Description	
Documentation Address	
Family	Series 90-70 PLC
Program Name	Target1
Update Rate (ms)	250
Sweep Time (ms)	Offline
PLC Status	Offline
Dual HWC	True
Selected HWC	Primary
Physical Port	COM1
<input type="checkbox"/> Additional Configuration	
Inspector	

Note: You can mirror as many times as necessary to synchronize the two HWCs after modifying the primary HWC. Each time you mirror the primary HWC, the secondary HWC is updated to reflect those changes.

 **Want to know more?** In the Help Index, look up “Redundancy”.

VersaMax Remote I/O



Navigator: VersaMax Remote I/O

VersaMax remote I/O consists of a Network Interface Unit (NIU) (Ethernet, Genius or Profibus), and one or more I/O modules. If your target type is remote I/O, you can use Logic Developer - PLC to configure this hardware. Once configured, the remote I/O can be controlled from a PLC or PC controller. The differentiating factor between a VersaMax remote I/O and a PLC is that a remote I/O is simply an input/output device with a communication interface. Unlike a PLC, a remote I/O has no CPU.

When working with the VersaMax Remote I/O hardware configuration, Logic Developer - PLC enables you to add racks, configure the power supply and configure modules.

Remote I/O targets are generally added to a project when you create a project with a template (see page 12). You can add additional Remote I/O targets later.

To create a project containing a GE Fanuc Remote I/O target from a template


1. From the **File** menu, choose **New Project**.
2. From the Project Template list, choose the GE Fanuc Remote I/O you want to add to your project.
3. Enter a descriptive Project Name.
4. Click **OK**.

The New Project dialog box appears.

A new Remote I/O project is started.




To add a GE Fanuc Remote I/O target to an existing project

1. In the Project tab of the Navigator, right-click the Project node.
2. Point to **Add Target**, then to **GE Fanuc Remote I/O**, and choose the remote I/O you want to add.




Note: The **Series 90-70 Genius** option is a Series 90™-70 Remote I/O Scanner.

To add a power supply to your remote I/O configuration


1. In the  Project tab of the  Navigator, expand the  Hardware Configuration node of the remote I/O.

The Navigator displays the following:



2. Right-click the  PwR node and choose **Replace Module**.

The Module catalogue dialog box appears:




3. From the list, select the power supply that you want to configure for your system.

To add a new Carrier/Base to your VersaMax Remote I/O


1. In the  Project tab of the  Navigator, select a  remote I/O target.
2. Expand the Hardware Configuration node and the Main Rack node.

The Navigator displays the following:



3. Right-click the  Slot 0 node and choose **Add Carrier/Base**.

The Module Catalog dialog box appears.



4. Select the carrier/base that you want to add to the remote I/O target.

Note: A maximum of eight carrier modules can be added to each VersaMax® rack.


5. Click **OK**.

To add a module to a carrier/base

1. Double-click an empty carrier/base.

The Module Catalog appears.


2. From the Module Catalog list, select the module that you want to install.




? Want to know more? In the Help Index, look up "Hardware Configuration".

Series 90™-70 Genius Remote I/O Scanner

A Remote I/O Scanner (IC697BEM733) is a Genius device that is part of a Genius Bus system. As such, it is added as a Genius device to the Genius Bus Controller (GBC) and it is represented in Logic Developer - PLC by an SBA node under the GBC node in a Series 90™-70 target.



**Navigator: Series 90™-70 Remote I/O Scanner
as a Genius device under a GBC**




**Navigator: Series 90™-70
Remote I/O Scanner
as a target and
as a module in Slot 1 of the main rack**

A Remote I/O Scanner resides in Slot 1 of the main rack of a Series 90™-70 PLC. I/O modules can be inserted into the other slots of the main rack and on all the slots of the other racks. As such, the Remote I/O Scanner is represented by a target in the Project tab of the Navigator, and is also represented by a module in slot 1 of the main rack of that target.


To set up a Remote I/O Scanner

1. Add the Remote I/O Scanner as a Genius device to the GBC.
2. When prompted to add a new target for the Remote I/O Scanner, click **Yes**.
Logic Developer - PLC automatically sets up some of the properties that link the Remote I/O Scanner to its GBC.
3. Set up the SBA to the same value to the Remote I/O Scanner as a target and to the Remote I/O Scanner as a Genius Device.
Now whenever you update the I/O map on the Remote I/O Scanner, the I/O map is automatically updated to the GBC.
4. Configure the Remote I/O Scanner's target properties.
5. Add and configure the I/O on the Remote I/O Scanner's rack system.
6. Configure the Remote I/O Scanner's module properties.
7. Configure the properties of the Remote I/O Scanner as a Genius bus device.





 **Want to know more?** In the Help Index, look up "IC697BEM733, Remote I/O Scanner".

5

Logic Editors




Logic is organized into blocks and user programs. Each block and user program is a named section of executable code. Blocks and programs are grouped into folders. The following logic types are supported by Logic Developer - PLC (not including motion programming) and are compiled and downloaded to the PLC represented by the associated GE Fanuc PLC target:

-  Ladder Diagram (LD)
-  Instruction List (IL)
-  C Blocks
-  C programs






Each target must contain one block named “_MAIN”. On any target except a release 6 or later Series 90™-70 PLC, the _MAIN block is first to execute when the project is downloaded to a PLC. Logic editors work in conjunction with global variables to operate and provide addressable units of logic that function as subroutines, called from another block.

Depending on the type of target PLC, blocks other than “_MAIN” can be scheduled for execution based upon timer or I/O interrupts.


Note: On release 6 or later of Series 90™-70 PLCs, the LD program can be scheduled. The Series 90™-70 PLC does not necessarily execute the _MAIN LD block first.

 **Want to know more?** In the Help Index, look up “LD Program”.


To schedule execution of a logic block

1. In the  Projects tab of the  Navigator, right-click an existing LD, C or IL block, and choose **Properties**.
The block's properties appear in the  Inspector.
2. In the  Inspector click the  button in the Scheduling field.

The Scheduling dialog box appears.



Inspector: IL, LD, C properties



3. Configure scheduling by entering values in each of the fields.

Want to know more? In the Help Index, look up "Scheduling."


To set access control

1. Right-click on an LD, IL or C Block and choose **Properties**.
2. In the Inspector, expand the Lock Settings property.
3. In the Lock Type property, choose a setting from the list.
4. In the Password property, enter a password.

After a lock type has been set, you must enter the password to change the setting. When a block is unlocked, the password is destroyed.

To search/replace in one block

1. Double-click an LD, IL, Local Logic, or Motion block to open it.
2. From the **Search** menu, choose **Find or Replace**.
A dialog box appears.
3. In the **Find what** or in the **Text to find** field, enter the text to find.
4. (Only if you want to replace text) In the **Replace with** field or in the **New text** field, enter the text to replace the found text with.
5. Select or clear each search/replace option, as required.
6. Click **Find**, **Find next**, **Replace**, **Replace All**, **Close**, or **Cancel**, as required.



Navigator: Project tab

Ladder Editor

LD EDITOR

The Ladder Diagram (LD) editor is used to create programs with the Ladder Diagram programming language. LD logic graphically represents the programmed actions performed by a PLC as it executes.




The LD editor is cell-based with rungs constructed of horizontal sequences of instructions that are wired together. A given instruction and its operands can occupy one or more cells.

You can work with the LD editor while offline to edit a disk copy of a project, or while online to monitor the execution of the logic while you fine tune the project by making word-for-word changes (see page 58).




You can customize the appearance and behavior of the LD editor.

An LD block is a named section of LD Logic that is compiled and downloaded to the PLC represented by the associated target. VersaMax and the Series 90-30 CPUs support a maximum of 64 Subroutine blocks plus one _MAIN block for a maximum of 65 blocks for a given target. The Series 90-70 CPUs support a maximum of 255 Subroutine blocks plus one _MAIN block for a maximum of 256 blocks for a given target.

To customize the LD editor

1. In the  Options tab of the Navigator, expand the Editors folder and then the Ladder folder.
2. Right-click a  page (Confirmations, Editing, Font and Colors, or View), and choose **Properties**.
The configurable settings appear as properties in the Inspector.
3. In the  Inspector, adjust settings as required.

To create an LD block

1. In the  Project tab of the  Navigator, right-click the  LD blocks folder and click **New**.

A new LD block with a default name is created.

Note: If you use a template or add a target, the first block added to a target is named “_MAIN” and subsequent blocks added are named LDBK1, LDBK2, and so on by default.

2. Rename the block as desired.

To open an LD block for editing

- In the  Project tab of the  Navigator, double-click an  LD block.

The block opens in the LD editor.

Note: You can have multiple blocks open for editing. To navigate to another open LD block, click the tab that displays its name at the bottom of the editor window.

Working with the LD Editor Offline

While in offline mode, there is no live communication between the LD editor and the target. Logic development is mostly done while offline. The following diagram illustrates some of the more common operations you can perform using the ladder editor offline.

The screenshot shows the SIMPLICITY Machine Edition interface. The main window displays a ladder logic diagram with rungs. A callout points to the top toolbar, stating: "Insert common instructions and wiring with the ladder instruction toolbar." Another callout points to the left-hand tree view, stating: "Drag variables to instruction operands to assign them." A third callout points to a right-click context menu over a rung, stating: "Right-click to insert an instruction." A fourth callout points to the Inspector window at the bottom left, which shows configuration for a BIT_SEQ instruction, stating: "Use the Inspector to configure address and length for instructions." A fifth callout points to the bottom status bar, stating: "The Companion tracks your moves and provides information on what you click." A sixth callout points to the right-hand pane, which lists various LD instructions, stating: "Drag LD instructions from the Toolchest." A seventh callout points to the bottom right pane, which shows a list of messages and errors, stating: "Locate syntax errors in the Build tab of the Feedback Zone." An eighth callout points to a comment rung in the ladder logic, stating: "In-place editor comment rungs."

To insert an instruction

1. In the LD editor, right-click an empty cell and chose **Place Instruction**.

A smart list appears listing all available instruction mnemonics.

2. Choose an instruction mnemonic from the list and press ENTER.


Note: Only a contact or a horizontal wire can be placed in the first column.

To configure an instruction's address and length properties

There are two methods to configure an instruction's address and length properties.


First method

1. In the LD editor, insert an instruction that requires Address and Length configuration.



2. Right-click the instruction and choose Properties.

The Inspector opens with the instruction's properties shown.




3. In the Address field, enter a variable name or a reference address to specify the start of a memory block.

Note: If you type a reference address, it is converted to a variable name automatically.

4. In the Length Field, enter the number of PLC registers that the instruction requires in the memory block.


Second method

1. In the LD editor, insert an instruction that requires Address and Length configuration.



2. Double-click the instruction or press ENTER.

The Function Properties dialog box appears.



3. In the Address field, enter a variable name or a reference address to specify the start of a memory block.
Note: If you type a reference address, it is converted to a variable name automatically.
4. In the Length field, enter the number of PLC registers that the instruction requires in the memory block.

To assign variables to instruction operands




1. In the LD editor, double-click beside an operand of an instruction, or click there and press ENTER.
A smart list appears prompting you to enter a variable name or reference address.
2. Type or choose from the list, a variable name or reference address.
If you enter a reference address, a variable name will be automatically substituted.

Working with the LD Editor Online

In online mode, there is a live connection to the target PLC enabling increased interaction with Logic Developer - PLC. The PLC's project must be equal to the current project for full functionality.

While online, the LD editor animates the LD logic to reflect program execution in the target PLC. Data values change in real time while coils and contacts indicate state flow. You can edit the LD program just as you would while offline. You can write the changed logic to the PLC while online.

To go online to a target PLC

- In the  Project tab of the  Navigator, right-click the  Target and choose **Go Online**.

The target icon changes and the status bar updates to reflect the online status. The LD editor, if equal to the PLC, displays various online features, as shown in the following illustration:

The screenshot shows the SIMPLICITY Machine Edition LD Editor interface. The main window displays a Ladder Logic (LD) diagram with a 'Run' coil and several normally open and normally closed contacts. Annotations include:

- Kung Number:** Points to the '1' in the top-left corner of the ladder logic diagram.
- State Flow is indicated by bolded lines.** Points to the bolded lines in the 'Run' coil and the 'Reset' coil.
- Online Status is indicated by the color of the target icon.** Points to the 'Target1' icon in the project tree on the left.
- Right-click a variable to force it.** Points to the 'V_R04' variable in the ladder logic diagram.
- PLC status and sweep time are displayed in real-time in the Inspector.** Points to the 'Inspector' panel at the bottom left, which shows 'Sweeptime (ms): 43' and 'PLC Status: Run Enabled'.
- A red, underlined variable indicates that it has been forced ON.** Points to the red, underlined variable '%Q00001' in the 'Reset' coil.
- Online indicator** points to the 'Online' indicator in the top right corner of the interface.
- Monitor and change values in real-time with the Data Watch tool.** Points to the 'Data Watch' tool at the bottom right, which shows a table of variables and their current values.
- Feedback Zone** points to the 'Feedback Zone' at the bottom center of the interface.
- PLC status is indicated in the status bar.** Points to the status bar at the bottom of the window, which shows 'True Enabled, Config EQ, Logic EQ, Sweep= 1.6 ms | Idnerney | LOCAL'.

Word-for-Word Changes

Word-for-word changes may be completed online to Series 90™-30, Series 90™-70, Series 90™ Micro, and VersaMax® modular PLCs. (VersaMax Nano/Micro PLCs do not support word-for-word changes).

Changes to the program that do not modify its size are considered word-for-word changes. Examples include changing the type of contact or coil, or changing a reference address used for an existing function block.

To make word-for-word changes

1. While online to a target PLC, make a change to LD logic that does not change the logic size. You are prompted to download the change.
2. Click **Yes**.

The changes are written to the PLC.

Writing Changes to a Target PLC

If you change the size of the program, you must write the changes to the PLC to maintain equality. Writing changes to a target PLC requires the PLC to be online and running. All PLC families support this run-mode store capability.

Note: If you go offline, you can do a regular download.

To write changes to the target PLC


1. While online to a target PLC that is running, make a change to LD logic.
2. In the  Project tab of the  Navigator, right-click the  target, point to **Online Commands** and choose **Write Changes**.

New logic is immediately written to the PLC without stopping the PLC. If the LD logic was altered, other than a word-for-word change, you are prompted to download to the running PLC. The entire target is validated, but only the changed blocks are downloaded.

To turn on/off or force a variable


- In the LD editor, right-click a BOOL variable anywhere in LD logic and choose **Force ON**, **Force OFF**, **Turn ON**, or **Turn OFF**.

Note: Forcing a variable ON or OFF overrides any actions the application may take during runtime. That is, if a variable is forced OFF (0), but LD logic is trying to turn it ON (1), it stays OFF.

 **Want to know more?** In the Help Index, look up "LD".

LD Functions

The following is a list of all LD functions available in Logic Developer - PLC. An asterisk (*) indicates the functions exclusive to Series 90™-70 PLCs. Companion help indicates which PLCs support the other functions.

 **Want to know more?** In the Help Index, look up "LD Functions".

Advanced Math

ACOS	COS	LN	SQRT_DINT	TAN
ASIN	EXP	LOG	SQRT_INT	
ATAN	EXPT	SIN	SQRT_REAL	

Bit Operations

AND_DWORD*	BIT_SET_DWORD*	NOT_WORD	SHIFTL_DWORD*
AND_WORD	BIT_SET_WORD	OR_DWORD*	SHIFTL_WORD
BIT_CLR_DWORD*	BIT_TEST_DWORD*	OR_WORD	SHIFTR_DWORD*
BIT_CLR_WORD	BIT_TEST_WORD	ROL_DWORD*	SHIFTR_WORD
BIT_POS_DWORD*	MASK_COMP_DWORD	ROL_WORD	XOR_DWORD*
BIT_POS_WORD	MASK_COMP_WORD	ROR_DWORD*	XOR_WORD
BIT_SEQ	NOT_DWORD*	ROR_WORD	

Coils

COIL	NEGCOIL	SETCOIL
CONTCOIL	POSCOIL	
NCCOIL	RESETCOIL	

Contacts

CONTCN	LOALR*	NOCON
FAULT*	NCCON	NOFLT*
HIALR*	NEGCON*	POSCON*

Control

DO_IO	EXIT_FOR*	PID_ISA	SVC_REQ
DRUM	FOR_LOOP*	SER	
END_FOR*	PID_IND	SUS_IO*	

Conversions

BCD4_TO_INT	DINT_TO_BCD8*	INT_TO_REAL	REAL_TO_WORD	UINT_TO_REAL*
BCD4_TO_REAL	DINT_TO_INT*	INT_TO_UINT*	TRUNC_DINT	WORD_TO_REAL
BCD4_TO_UINT*	DINT_TO_REAL	RAD_TO_DEG	TRUNC_INT	
BCD8_TO_DINT*	DINT_TO_UINT*	REAL_TO_DINT	UINT_TO_BCD4*	
BCD8_TO_REAL*	INT_TO_BCD4	REAL_TO_INT	UINT_TO_DINT*	
DEG_TO_RAD	INT_TO_DINT*	REAL_TO_UINT*	UINT_TO_INT*	

Counters

DNCTR	UPCTR
-------	-------

Data Move

BLK_CLR_WORD	DATA_INIT_DLAN*	MOVE_UINT*	VME_RMW_BYTE*
BLKMOV_DINT*	DATA_INIT_DWORD*	MOVE_WORD	VME_RMW_WORD*
BLKMOV_DWORD*	DATA_INIT_INT*	SHFR_BIT	VME_TS_BYTE*
BLKMOV_INT	DATA_INIT_REAL*	SHFR_DWORD*	VME_TS_WORD*
BLKMOV_REAL	DATA_INIT_UINT*	SHFR_WORD	VME_WRT_BYTE*
BLKMOV_UINT*	DATA_INIT_WORD*	SWAP_DWORD*	VME_WRT_WORD*
BLKMOV_WORD	MOVE_BOOL	SWAP_WORD*	
COMM_REQ	MOVE_DINT*	VME_CFG_READ*	
DATA_INIT_ASCII*	MOVE_DWORD*	VME_CFG_WRITE*	
DATA_INIT_COMM*	MOVE_INT	VME_RD_BYTE*	
DATA_INIT_DINT*	MOVE_REAL	VME_RD_WORD*	

Data Table

ARRAY_MOVE_BOOL	FIFO_WRT_WORD*	SEARCH_GE_UINT*	SEARCH_NE_DINT
ARRAY_MOVE_BYTE	LIFO_RD_DINT*	SEARCH_GE_WORD	SEARCH_NE_DWORD*
ARRAY_MOVE_DINT	LIFO_RD_DWORD*	SEARCH_GT_BYTE	SEARCH_NE_INT
ARRAY_MOVE_DWORD*	LIFO_RD_INT*	SEARCH_GT_DINT	SEARCH_NE_UINT*
ARRAY_MOVE_INT	LIFO_RD_UINT*	SEARCH_GT_DWORD*	SEARCH_NE_WORD
ARRAY_MOVE_UINT*	LIFO_RD_WORD*	SEARCH_GT_INT	SORT_INT*
ARRAY_MOVE_WORD	LIFO_WRT_DINT*	SEARCH_GT_UINT*	SORT_DINT*
ARRAY_RANGE_DINT*	LIFO_WRT_DWORD*	SEARCH_GT_WORD	SORT_WORD*
ARRAY_RANGE_DWORD*	LIFO_WRT_INT*	SEARCH_LE_BYTE	TBL_RD_DINT*
ARRAY_RANGE_INT*	LIFO_WRT_UINT*	SEARCH_LE_DINT	TBL_RD_DWORD*
ARRAY_RANGE_UINT*	LIFO_WRT_WORD*	SEARCH_LE_DWORD*	TBL_RD_INT*
ARRAY_RANGE_WORD*	SEARCH_EQ_BYTE	SEARCH_LE_INT	TBL_RD_UINT*
FIFO_RD_DINT*	SEARCH_EQ_DINT	SEARCH_LE_UINT*	TBL_RD_WORD*
FIFO_RD_DWORD*	SEARCH_EQ_DWORD*	SEARCH_LE_WORD	TBL_WRT_DINT*
FIFO_RD_INT*	SEARCH_EQ_INT	SEARCH_LT_BYTE	TBL_WRT_DWORD*
FIFO_RD_UINT*	SEARCH_EQ_UINT*	SEARCH_LT_DINT	TBL_WRT_INT*
FIFO_RD_WORD*	SEARCH_EQ_WORD	SEARCH_LT_DWORD*	TBL_WRT_UINT*
FIFO_WRT_DINT*	SEARCH_GE_BYTE	SEARCH_LT_INT	TBL_WRT_WORD
FIFO_WRT_DWORD*	SEARCH_GE_DINT	SEARCH_LT_UINT*	
FIFO_WRT_INT*	SEARCH_GE_DWORD*	SEARCH_LT_WORD	
FIFO_WRT_UINT*	SEARCH_GE_INT	SEARCH_NE_BYTE	

Math

ABS_DINT*	ADD_UINT*	MOD_DINT	MUL_REAL	SUB_REAL
ABS_INT*	DIV_DINT	MOD_INT	MUL_UINT*	SUB_UINT*
ABS_REAL*	DIV_INT	MOD_UINT*	SCALE_INT	
ADD_DINT	DIV_MIXED*	MUL_DINT	SCALE_WORD	
ADD_INT	DIV_REAL	MUL_INT	SUB_DINT	
ADD_REAL	DIV_UINT*	MUL_MIXED*	SUB_INT	

Program Flow

CALL	ENDMCR	JUMP	LABELN	V_WIRE
COMMENT	ENDMCRN	JUMPN	MCR	
END	H_WIRE	LABEL	MCRN	


Relational

CMP_DINT*	EQ_UINT*	GT_REAL	LT_INT	RANGE_DINT
CMP_INT*	GE_DINT	GT_UINT*	LT_REAL	RANGE_DWORD*
CMP_REAL*	GE_INT	LE_DINT	LT_UINT*	RANGE_INT
CMP_UINT*	GE_REAL	LE_INT	NE_DINT	RANGE_UINT*
EQ_DINT	GE_UINT*	LE_REAL	NE_INT	RANGE_WORD
EQ_INT	GT_DINT	LE_UINT*	NE_REAL	
EQ_REAL	GT_INT	LT_DINT	NE_UINT*	

Timers

OFDT_HUNDS	ONDTR_HUNDS	TMR_HUNDS
OFDT_SEC*	ONDTR_SEC*	TMR_SEC*
OFDT_TENTHS	ONDTR_TENTHS	TMR_TENTHS
OFDT_THOUS	ONDTR_THOUS	TMR_THOUS

Note: An asterisk (*) indicates the functions exclusive to Series 90™-70 PLCs.



Navigator: Project tab

IL Blocks nodes

IL EDITOR

Instruction List (IL) is a programming language specified by the IEC 61131-3 standard. This text language is accumulator-based and much like the assembly languages used for programming microprocessors. The instructions executed by the IL program modify or use an accumulator that is located in PLC memory. Two types of accumulators are defined: one analog accumulator for numeric and bitwise operations and eight boolean accumulators for discrete logic to support eight levels of nested boolean expressions. The IL editor is free-form with an option to apply a standard formatting rule. The appearance and behavior of the IL editor is user-configurable.

Note: IL logic is not supported on Series 90™-70 PLCs.

To configure accumulators

1. In the Project tab of the Navigator, right-click the IL Blocks folder and choose **Properties**.
The Inspector opens, displaying the Accumulator Address properties.
2. In the Boolean Start field, enter the reference address of the first of eight PLC memory locations to use for boolean accumulators.
The ending address is calculated automatically. The memory area must be %T, %M, or %Q.
3. In the Analog Start field, enter the PLC memory locations to use for the analog accumulator.
The ending address is calculated automatically. The memory area must be %R, %AI or %AQ.

To create an IL block

1. In the Projects tab of the Navigator, right-click the IL blocks folder and choose **New**.
An empty IL block with the default name "ILBkn" is added to the folder, where *n* represents a unique number.
2. Rename the block as desired.

To open an IL block for editing

- In the Project tab of the Navigator, right-click an IL Block and choose **Open**.
The block opens in the IL editor.

Note: You can have multiple blocks open for editing. To navigate to another open IL block, click the tab displaying its name at the bottom of the editor window.

Working with the IL Editor Offline

Most project development is carried out while offline from the target PLC. Editing while offline provides maximum flexibility in editing and allows you to interact with the Machine Edition tools as shown in the following diagram.

The screenshot shows the SIMATIC Manager IL Editor interface. The main window displays a ladder logic program with the following code:

```

Created: Friday, February 02, 2001

This is a test of Basic Boolean IL Logic. When r
Test Discrete Variables should be ON.

'Boolean Storage Cases
LD_BOOL #ALW_ON
ST_BOOL Test_STBool
LD_BOOL #ALW_OFF
STH_BOOL Test[BOOL Target1 #ALW_OFF]

'Boolean Operators TRUE Cases
LD_BOOL #ALW_ON
AND #ALW_ON
ST_BOOL Test_AND_T
OR #ALW_OFF
ST_BOOL Test_OR_T
LD_BOOL #ALW_OFF

```

Annotations and their descriptions:

- The Variables tab of the Navigator lists all the variables in your projects.** (Points to the Variables list on the left side of the editor.)
- Drag and drop variables from the Variables list into the IL editor.** (Points to a variable being dragged from the list to the code area.)
- A description of a variable pops up when you hover the mouse over it.** (Points to the tooltip for the variable `Test[BOOL Target1 #ALW_OFF]`.)
- Configure accumulators in the Inspector.** (Points to the Inspector window showing accumulator settings.)
- The Companion tracks all of your moves and provides information on what you click.** (Points to the Companion window showing the definition of the `ADD_DINT` instruction.)
- Right click in the IL Editor to insert an instruction or variable.** (Points to the context menu that appears when right-clicking in the code area.)
- The Build tab of the Feedback Zone lists error messages when you validate.** (Points to the Build tab in the Feedback Zone at the bottom of the interface.)

To insert an instruction or function


1. In the IL editor, right-click and choose Insert Keyword.
A smart list appears listing all available instruction mnemonics.
2. From the list select an instruction and press ENTER.
The instruction is inserted in your logic.

To assign operands to an instruction

1. In the IL editor, right-click and choose Insert Variable.
A smart list appears showing all your defined variables.
2. Type or choose from the list, a variable name or reference address and then press ENTER.
The name appears in your logic.

Note: If you entered a reference address or a new variable name, you must create a variable from it.

To create a variable from a reference address

1. In the  IL editor, right-click a reference address, point to **Create “name” as**, and then choose a data type.

A variable is created and a default name is applied. For example, if the reference address is %R0032, the auto-created variable is named R00032.


To create a variable from a name

1. In the  IL editor, right-click a name, point to **Create “name” as**, and then choose a data type.

A variable is created with the name you right-clicked.


2. Map the variable to PLC memory. (See page 17.)

To move or duplicate IL logic

1. In the  IL editor, select a range of logic.
2. To move it, click the selection and drag it to a new location. To duplicate it, press CTRL while clicking the selection, and drag the selection to where you want to place the duplicate.


When you release the mouse button, the selection is respectively moved to the new location or a duplicate copy of the selected logic is placed in the new area.

To insert an inline comment

1. In the  IL editor, click where you want to insert an inline comment.
2. Type an apostrophe (') followed by comment text.

Press ENTER to complete the comment.

To insert a block comment

1. In the  IL editor, click where you want to insert a block comment.
2. Type (* followed by comment text.

A block comment can contain any number of characters and can span multiple lines.

3. Type *) to complete the block comment.

To reformat IL code

- In the  IL editor, right-click and choose **Beautify Source**.

The entire content of the IL editor is reformatted according to the default formatting (indentation) rules.

Working with the IL Editor Online

While online to a target PLC, the IL editor enables you to edit logic, monitor data values and change or force the state of BOOL variables in real-time. This allows you to test the execution of logic, to trigger an event within an executing project, or to remove an element from logic execution.

Target icon changes to indicate status of the PLC.

Right-click a BOOL to change or force its state.

The Feedback Zone indicates that a connection has been established with the PLC.

Monitor and change variable values in the Data Watch.

PLC status is indicated in the status bar.

Hover over a variable to show a popup of its value.

The Companion tracks your moves and provides information on what you click.

To monitor a data value

- Click anywhere in the IL editor and hover the mouse pointer over a variable.

A tooltip appears, showing the variable's current value. This value, however, does not update. You must move the mouse pointer away and back over the variable.

To change a BOOL variable's state

- In the IL editor, right-click the BOOL variable whose value you want to change and choose **Turn On** or **Turn Off**.

The state of the variable in the target PLC changes when the command is received. It remains in that state until acted on by the PLC's logic.

To force a BOOL variable's state

- In the  IL editor, right-click a BOOL variable and choose **Force On** or **Force Off**.

The state of the forced variable will remain unchanged, regardless of any actions by the PLC's logic.

To remove the force from a BOOL variable

- In the  IL editor, right-click a BOOL variable and choose **Remove Forces**.

The state of the forced variable will be controlled by the PLC's logic.




Writing Changes to a Target PLC

You can change your IL logic while online, but you must write the changes to the PLC to maintain equality. Writing changes to a target PLC requires the PLC to be online and running.


Note: If you go offline, you can do a regular download.

To write changes to the target PLC (if the target PLC supports it)

1. While online to a target PLC, make a change to IL logic.

In the  Project tab of the  Navigator, right-click the  target, point to **Online Commands**, and choose **Write Changes**.

You are prompted to confirm a run mode store. That is, the altered IL block will be downloaded to the PLC without stopping the PLC.

 **Want to know more?** In the Help Index, look up "IL"

IL Instructions and Functions

The following is a list of all IL instructions and functions available in Logic Developer - PLC. An asterisk (*) indicates the functions exclusive to VersaMax® PLCs. Companion help indicates which PLCs support the other functions.

Basic Instructions

ADD	CAL	GT	MOD	NT	R	SUB
AND	DIV	LE	MUL	OR	RET	XORN
AND_WORD	EQ	LT	NE	ORN	RETC	
ANDN	GE	MCRN	NOT	PT	S	

Advanced Math

ACOS	COS	LN	SQRT_INT	TAN
ASIN	EXP	LOG	SQRT_DINT	
ATAN	EXPT	SIN	SQRT_REAL	

Bit Operations

AND_WORD	BIT_SEQ	MASK_COMP_DWORD	OR_WORD	SHIFTL_WORD
BIT_CLR_WORD	BIT_SET_WORD	MASK_COMP_WORD	ROL_WORD	
BIT_POS_WORD	BIT_TEST_WORD	NOT_WORD	ROR_WORD	

Control

DO_IO	PID_ISA
DRUM	SER
PID_IND	SVC_REQ

Conversions

BCD4_TO_INT	DINT_TO_REAL	RAD_TO_DEG	REAL_TO_WORD	WORD_TO_REAL
BCD4_TO_REAL	INT_TO_BCD4	REAL_TO_DINT	TRUNC_DINT	
DEG_TO_RAD	INT_TO_REAL	REAL_TO_INT	TRUNC_INT	

Counters

DNCTR	UPCTR
-------	-------

Data Move

BLK_CLR_WORD	BLKMOV_DINT	MOVE_BOOL	MOVE_WORD
BLKMOV_INT	COMM_REQ	MOVE_REAL	SHFR_WORD
BLKMOV_REAL	MOVE_INT	SHFR_BIT	

Data Table

ARRAY_MOVE_BOOL	SEARCH_EQ_INT	SEARCH_GT_DINT	SEARCH_LT_BYTE	SEARCH_NE_WORD
ARRAY_MOVE_BYTE	SEARCH_EQ_WORD	SEARCH_GT_INT	SEARCH_LT_DINT	
ARRAY_MOVE_DINT	SEARCH_GE_BYTE	SEARCH_GT_WORD	SEARCH_LT_INT	
ARRAY_MOVE_INT	SEARCH_GE_DINT	SEARCH_LE_BYTE	SEARCH_LT_WORD	
ARRAY_MOVE_WORD	SEARCH_GE_INT	SEARCH_LE_DINT	SEARCH_NE_BYTE	
SEARCH_EQ_BYTE	SEARCH_GE_WORD	SEARCH_LE_INT	SEARCH_NE_DINT	
SEARCH_EQ_DINT	SEARCH_GT_BYTE	SEARCH_LE_WORD	SEARCH_NE_INT	

Math

ADD_DINT	DIV_DINT	MOD_DINT	MUL_DINT	SCALE_WORD*	SUB_REAL
ADD_INT	DIV_INT	MOD_INT	MUL_REAL	SUB_DINT	
ADD_REAL	DIV_REAL	MUL_INT	SCALE_INT*	SUB_INT	

Program Flow


CALL	ENDMCR	JUMP	LABELN	V_WIRE
COMMENT	ENDMCRN	JUMPN	MCR	
END	H_WIRE	LABEL	MCRN	

Relational

EQ_DINT	GE_DINT	GT_DINT	LE_DINT	LT_DINT	NE_DINT	RANGE_DINT
EQ_INT	GE_INT	GT_INT	LE_INT	LT_INT	NE_INT	RANGE_INT
EQ_REAL	GE_REAL	GT_REAL	LE_REAL	LT_REAL	NE_REAL	RANGE_WORD

Timers

OFDT_HUNDS	ONDTR_HUNDS	TMR_HUNDS
OFDT_TENTHS	ONDTR_TENTHS	TMR_TENTHS
OFDT_THOUS	ONDTR_THOUS	TMR_THOUS



Navigator: Project tab

C Blocks node

C BLOCKS

A C block is an independent section of executable code written in the C programming language, that is downloaded to and executed on the target PLC. C blocks are created externally using GE Fanuc's C Programming Toolkit and then imported into a project. A C block is an .exe file and can be called as a subroutine from another block (LD or IL) but cannot call another block.


For more information on developing C Blocks, refer to *GFK-0646 E, C Programmer's Toolkit for Series 90 PLC's*.

Working with C blocks

To import a C block

1. In the Projects tab of the Navigator, right-click the C Blocks folder and choose Add.

The Open dialog box appears.






2. Browse to the .exe file you want to import and click **Open**.


The .exe file is added to the C Blocks folder with the same name as the .exe file.

Want to know more? In the Help Index, choose "C".

To set a C block's parameters

Note: This procedure applies only to Series 90™-70 PLCs and to C blocks that were written to require parameters.

1. In the  Projects tab of the  Navigator, right-click the  C block and choose **Properties**.


The  Inspector opens, showing the block's properties.


2. In the Inspector, select the Parameters property and click the  .

The Parameters dialog box opens.

3. Type a name and description for each required input and output parameter.

For information on the required parameters, consult the written documentation for the C block. The names you enter will display in the CALL instruction. The names and descriptions will display as tooltip help when you hover over the CALL instruction.

 **Want to know more?** In the Help Index, enter "Parameterized" and select the "C Block" help topic.



Navigator: Project Tab

C Programs node

C PROGRAMS

Note: C programs are supported only on Series 90™-70 CPUs, firmware release 6.00 and later.

A C program is an independent section of executable code, written in C language, that is downloaded to and executed on the associated target PLC.

A C program has access to all the % reference tables of the PLC except for the _MAIN LD block's %P memory and the %L memory of any other LD block. A C program can also call any of the numerous PLC-embedded function blocks, which are included in the C Programmer's Toolkit.

A C program cannot be called as a subroutine. Execution is controlled only through scheduling. A C program cannot call another block as a subroutine.

By setting the parameters of a C program, you enable it to access memory directly. When a C program begins to execute, it reads the data for all the parameters and makes a copy of the data. If the C program's execution is interrupted or time-sliced over multiple scans, the C program, when it resumes execution, uses the copy of the data that it made upon beginning to execute.

The maximum number of C programs that can be used on a target depends on the nature of the _MAIN block:

- If the _MAIN block is an LD block, the LD program is treated as a user program and can be scheduled, and the maximum number of C programs per target is 15.
- If the _MAIN block is not an LD block, the maximum number of C programs per target is 16, and the LD program cannot be scheduled.

C programs can coexist with State Logic on a Series 90-70 PLC. For such a target, the State Logic is compiled into a C program. This C program is named _MAIN if there is no LD logic; however, if State Logic coexists with LD logic, the State Logic is compiled into a C program named _STATE and one LD block must be named _MAIN.


User Programs

User programs consists of:

- C programs
- The LD program, if the _MAIN block is an LD block.

Working with User Programs

To configure execution scheduling

1. In the  Projects tab of the  Navigator, right-click a  C program or the `_MAIN` LD block, and choose **Properties**.




The  Inspector opens, showing the user program's properties.


2. In the Inspector, expand the **Scheduling** property.
3. Select a Schedule Mode.
4. Select the other properties used in the schedule mode you selected.
5. Click **OK**.

Note: If you made any entries, they are checked when you click **OK**. You must correct any errors before you can close the dialog box with the OK button.

Setting a C program's parameters

Note: You must provide a list of all the input and output parameters that the C program requires. The LD program does not use parameters.


1. In the  Projects tab of the  Navigator, right-click a  C program and choose **Properties**.

The  Inspector opens, showing the C program's properties.

2. In the Inspector, select the **Parameters** property and click  .


The Parameters dialog box opens.

3. On the **Input** and **Output** tabs, enter up to 8 input and up to 8 output parameters. Each parameter has its own row on the tab. For each parameter, double-click the following cells and enter the required data:
 - **Name:** The parameter's name.
 - **Type:** The parameter's data type.
 - **Length:** The length of the input or output reference.
 - **Variable:** The first data item associated with the parameter.
 - **Description:** (Optional) The parameter's description.

 **Want to know more?** In the Help Index, choose "C Program".

6

Motion Programming



Navigator: Project tab

Motion Program nodes


Logic Developer - PLC supports motion programming for the Motion Mate DSM314 motion control module. A high performance, easy-to-use, multi-axis motion control module, the Motion Mate DSM314 is highly integrated with the Series 90-30 PLC logic solving and communication functions.

The DSM314 (see page 38) supports 10 motion programs, 40 subroutines and a maximum total of 1000 motion program statements. Logic Developer - PLC, making motion programming possible, supports the following motion editors:

- PLC Motion Editor
- Local Logic Editor
- CAM Editor

This chapter outlines basic procedures that will get you started with Logic Developer - PLC to create motion programs, using these three motion editors.

To add a Motion component to a target



Target right-click menu


- In the Project tab of the Navigator, right-click the target, point to **Add Component** and then choose **Motion**.

A Motion Program node is added to your project. Included are empty Motion Blocks, Local Logic, CAM Profiles and CAM Blocks folders.

PLC MOTION EDITOR

Logic Developer - PLC includes a PLC Motion Editor, which enables you to create PLC Motion blocks for the DSM314. This text-based editor is configurable as to its appearance and behavior. Comments and white space are not considered as PLC Motion program statements. Motion programming has a different programming syntax from Local Logic.

To add a Motion Block



Navigator: Project tab

Motion Blocks

1. In the Project tab of the Navigator, expand the Motion Program folder.
2. Right-click the Motion Blocks folder and choose **New**.

A new empty PLC Motion block with a default name is added to your project.

3. Rename the block as desired.

To open a motion block for editing

- In the Project tab of the Navigator, right-click the **Motion Block** node and choose **Open**.

The block opens for editing in the PLC Motion editor

Working with the Motion Editor


To insert a command

1. In the  Motion editor, right-click and choose **Insert Keyword**.

A smart list appears showing all available motion commands.

2. Select the appropriate command from the smart list and press **ENTER**.

The command is placed in the motion editor.




Insert a PLC Motion command by choosing a keyword.

Insert a PLC Motion variable by selecting a variable from the smart list.

The Companion tracks all mouse clicks.


The Feedback Zone indicates that a connection has been established with the PLC.

 **Want to know more?** In the Help Index, choose "PLC Motion Editor".

Motion Commands

ACCEL	The ACCEL statement sets the axis acceleration for subsequent moves and remains in effect in a given program unless changed. Note: If a move instruction is executed before ACCEL, the tag Acceleration is used.
BLOCK NUMBER	Block numbers may be used as the destination of JUMP commands. Block numbers must be unique and can be between 1 and 65535.
CAM	The CAM statement runs a CAM profile.
CAM PHASE	CAM PHASE set the phase of a CAM profile.
CAM MARKER	CAM LOAD loads a CAM profile.
CALL	The CALL command executes another block as a subroutine
CMOVE	The CMOVE command programs a continuous move using the specified position and acceleration mode.
DWELL	DWELL causes motion to cease for a specified time period before processing the next command.
ENDP	The ENDPROG statement terminates a PLC Motion program definition.
ENDS	The ENDSUB statement terminates a PLC Motion subroutine definition.
JUMP	Jump to a block number or a sync block within the current program or subroutine. The jump may be conditional or unconditional based on the status of a CTL bit.
LOAD	Initializes or changes a parameter data register with a 32-bit two's-complement integer value.
PMOVE	The PMOVE command programs a positioning move using the specified position and accelerator mode.
PROGRAM	The PROGRAM statement is the first statement in a motion program. The program statement identifies the program number (1-10) and the axis configuration. Program definitions cannot nest.
SUBROUTINE	The SUBROUTINE statement is the first statement in a motion subroutine. The subroutine statement identifies the subroutine number (1-40) and the axis configuration.
SYNC BLOCK	A sync block is a special case of a block number. A sync block may only be used in multi-axis programs.
VELOC	Sets the process VELOCITY used by subsequent motion program move commands and remains in effect until changed by another VELOC statement.

LOCAL LOGIC



Navigator: Project tab

Local Logic

A Local Logic program runs synchronously with the Motion program, but is independent of the PLC's CPU scan. This allows the DSM314 to interact much more quickly with motion I/O signals on its faceplate connectors than would be possible if the logic for the signals was handled in the main ladder program running on the PLC.

Local Logic language uses free-form, text-based circuits and contains basic mathematical and logical constructs. Local Logic programming syntax allows you to assign a variety of logic tasks to your motion programs while working in conjunction with PLC Logic programs and motion programs to yield a flexible programming environment. Because it uses straightforward, understandable syntax, it is easy to gain proficiency with this editor.

The Local Logic programming language supports assignments, conditional statements, arithmetic, logical and relational statements. Local Logic provides the user access to motion controller data, parameters using a fixed set of variables, control and status bits.

- Parameter data - accessible from Local Logic host PLC and motion programs. The parameter data are similar to variables in a program.
- CTL bits - allow the Local Logic program or host PLC to signal the motion program to start an event.
- Motion program block numbers - the current block number can be used within the Local Logic program or host PLC to make an action occur only during a specific motion programming section.

To create a Local Logic block

1. In the Projects tab of the Navigator, right-click the Local Logic folder and choose **New**.
A new Local Logic block with a default name is created.
Note: The Local Logic folder can contain only one Local Logic block.
2. Rename the block as required.

To open a Local Logic block for editing

- In the Projects tab of the Navigator, right-click the Local Logic block and choose **Open**.
The Local Logic block opens in the Local Logic editor and is ready for editing.

Working with Local Logic Editor

The Local Logic editor has its own distinctive syntax for constructing Local Logic programs.

Navigator shows the organization of your project.

Drag and drop variables from the Local Logic Variable table into the Local Logic editor.

NAME	TYPE	GROUP	DESCRIPTION	R	W
Actual_Position_1	32 Bits	Status Variables	Actual_Position (user units)	X	
Actual_Velocity_1	32 Bits	Status Variables	Actual_Velocity (user units/sec)	X	
Analog_Inpt_1	Signed 16 Bits	FacePlate I/O	Analog Input 1 w/ 32000 = +/- 10.0v		X
Enable_Follower_1	Bit	Control Variables	Set this bit = 1 to enable the follower		X
Error_Code	Unsigned 16 Bits	Status Variables	Axis 1 Error Code	X	
FeedHold_1	Bit	Control Variables	Set this bit = 1 to initiate feedhold	X	
Follower_Enable	Bit	Status Variables	ON when follower is enabled	X	
Follower_Ramp_1	Bit	Status Variables	ON when follower accel / decel ramp is active	X	
Follower_Ratio	Signed 16 Bits	Control Variables	Ratio A:cmd for follower A:B (slave:master) ratio	X	

```

Created: 06/16/2001
Description:

IF First_Local_Logic_Sweep THEN      (* IF ... sweep then *)
  P001:=0;                          (* Initial...
  P003:=0;                          (* Initial...
  P004:=0;                          (* Initial...
END_IF;

P001:=P001 + 2;                      (* Time in Mill...

P100:=P001 MOD 1000;                (* Check to see in 1 Sec (1000 mSec) Passed *)
IF P100 = 0 THEN                    (* IF Remainder of MOD Operation = 0, 1 Sec Passed *)

```

Right-click to choose commands from a list.

To insert a Local Logic command

1. In the Local Logic editor, right-click and choose **Insert Keyword** from the menu.

A smart list appears showing all available Local Logic commands.

2. Select the desired command in the smart list and press **ENTER**

The command is inserted.

Note: You can drag variables from the Local Logic Variable Table to the Local Logic editor.

Local Logic Variables

Local Logic is designed to complement a PLC's logic and mathematical capabilities. Solving small Local Logic and mathematical sets require a tight synchronization with the controlled motion.

Logic Developer - PLC includes a table containing Local Logic variables, the Local Logic Variable Table (LLVT), that you can drag into your logic programs. As illustrated in the diagram below, the LLVT has several tabs that organize the variables by category:

Click a heading to sort the table in ascending order. Click again to sort descending.

Right-click a name to copy it to the clipboard.

Click a tab to view a group of variables

NAME	TYPE	GROUP	DESCRIPTION	R	W
Actual_Position_1	32 Bits	Status Variables	Actual_Position (user units)	X	
Actual_Velocity_1	32 Bits	Status Variables	Actual_Velocity (user units/sec)	X	
Analog_Input1_1	Signed 16 Bits	FacePlate I/O	Analog Input 1 +/- 32000 = +/- 10.Dv	X	
Analog_Input2_1	Signed 16 Bits	FacePlate I/O	Analog Input 2 +/- 32000 = +/- 10.Dv	X	
Axis_OK_1	Bit	Status Variables	ON when axis is ready for commands	X	
Block_1	Unsigned 16 Bits	Status Variables	Motion program block number	X	
Commanded_Position_1	32 Bits	Status Variables	Commanded_Position (user units)	X	
Commanded_Torque_1	32 Bits	Status Variables	Reports digital servo torque in units of 0.01%	X	
Commanded_Velocity_1	32 Bits	Status Variables	Commanded_Velocity (user units/sec)	X	
Digital_Output1_1	Bit	FacePlate I/O	Set this bit = 1 to turn on 24v output OUT1_A		X
Digital_Output3_1	Bit	FacePlate I/O	Set this bit = 1 to turn on 5v output OUT3_A		X
Drive_Enabled_1	Bit	Status Variables	ON when enable output to servo is active	X	
Enable_Follower_1	Bit	Control Variables	Set this bit = 1 to enable the follower		X
Error_Code_1	Unsigned 16 Bits	Status Variables	Axis 1 Error Code	X	
FeedHold_1	Bit	Control Variables	Set this bit = 1 to initiate feedhold		X
Follower_Enabled_1	Bit	Status Variables	ON when follower is enabled	X	
Follower_Ramp_Active_1	Bit	Status Variables	ON when follower accel / decel ramp is active	X	

InfoViewer LLBK3

To view the LLVT

1. In the InfoViewer tab of the Navigator, expand the Logic Developer - PLC library then expand the Local Logic Editor book and double-click Local Logic Variable Table.

The LLVT appears in the Infoviewer.

The variables or data in each tab are:

Axis 1	Variables specific to axis 1
Axis 2	Variables specific to axis 2
Axis 3	Variables specific to axis 3
Axis 4	Variables specific to axis 4
Global	Global data such as module status code
CTL bits	DSM general Control/Status bits
Parameter Registers	DSM parameter data

The table has six columns:

Name	Contains the variable name that is to be used within a Local Logic program
Type	The data type for this variable. For example, 32-bit means that this variable is a 32-bit variable.
Group	The group this variable is placed in. For example, Faceplate I/O means that this variable refers to a point on the module faceplate.
Description	This column contains a textual description of the variable. When the user hovers the mouse pointer over the description, a tool tip displays the description.
R	This column indicates if the variable can be read by a Local Logic program.
W	This column indicates if the variable can be written by a Local Logic program.

To insert a Local Logic variable

1. In the Local Logic editor, right-click and choose **Insert Variable**.

A smart list appears prompting you to choose a Local Logic variable name.

2. Select a variable in the list and press ENTER.

The variable is inserted in your Local Logic.

Local Logic Commands and Operators

Local Logic provides the capability of executing basic logic and mathematical functions on the DSM module. Commands use upper case characters only and are case sensitive.


ABS	TRUE	-(minus)	<= (less than or equal to.)
BWAND	FALSE	/(divide)	<> (not equal)
BWOR	IF	*(multiply)	
BWXOR	THEN	:=(assign)	
BWNOT	END_IF	>(greater than)	
ON	MOD	< (less than)	
OFF	+ plus	>= (greater than or equal to.)	

 **Want to know more?** In the Help Index, choose "Local Logic: an Overview".

CAM EDITOR

The CAM editor is an accessory for Logic Developer - PLC motion programming that provides a means to create, edit, and manage electronic CAM profiles. Each CAM profile is a curve that specifies the response of a slave servo to a master position index. CAM profiles are referenced by name in the associated motion program and grouped into CAM blocks. Each block is intended for download to a specific motion module by means of a PLC controller. The hardware components are specified in the HWC for the associated project.

CAM profiles are user-defined in a library and then grouped into blocks by aliasing them. This allows you to reuse CAM profiles by including them in multiple CAM blocks.



Project Tab: Navigator

CAM Blocks

To create a CAM block

1. In the Project tab of the Navigator, expand the Motion Program folder.
2. Right-click the CAM blocks folder and choose **New**.
A new CAM block with a default name is created.
3. Rename the block as desired.

To import CAM blocks

1. In the Project tab of the Navigator, expand the Motion Program folder.
2. Right-click the CAM blocks folder and choose Import from File.
The Open dialog box appears.
3. Browse to the CAM block you want to import (.csv or .txt file).
4. Click Open.
The imported block appears in your project.

Working with the CAM Editor

You can adjust the curves of your CAM profile to suit the specific needs of your project. With the CAM editor you create profiles by defining points on a master/slave position curve. Groups of adjoining points are allocated to sectors. Each sector is assigned a polynomial curve fit order (1,2,3) that specifies how the curve will be interpolated between points.

The screenshot shows the CAM Editor interface with the following components and callouts:

- Navigator:** Displays CAM profiles and blocks. Callout: "Navigator displays CAM profiles and blocks."
- CAM profile table:** Allows numeric editing and curve order grouping. Callout: "CAM profile table allows numeric editing and curve order grouping"
- Inspector:** Used to configure profiles and blocks. Callout: "Configure profiles and blocks in the Inspector."
- Companion:** Tracks moves and provides information on what you click. Callout: "The Companion tracks your moves and provides information on what you click."
- Position Graph:** Shows the master/slave position curve. Callout: "Curves of the profile can be adjusted and edited graphically."
- Velocity/Accel/Jerk Graph:** Shows secondary curves for velocity, acceleration, and jerk. Callout: "Secondary curves show the velocity, acceleration and jerk of the CAM profile."

Master Position	Slave Position
0	0
76	-50659
127	491535
207	49767
219	70231
278	384022
282	260
389	593871
400	7565
436	13
438	248
440	7
450	6175
533	745245
580	446741
620	796331
642	59797
665	12
720	20845
960	540905
1000	0
1029	643076
1123	452047
1280	0

To create a CAM profile

- In the **Project** tab of the **Navigator**, right-click the **CAM Profiles** folder and choose **New**.
A new CAM profile with a default name is added to your project.

To configure a CAM profile

1. In the **Project** tab of the **Navigator**, right-click a **CAM profile** and choose **Properties**.
The properties of the CAM profile appear in the **Inspector**
2. Adjust the properties of the CAM profile in the **Inspector** to specify its type and boundary conditions.


To edit a CAM profile

1. In the  Project tab of the  Navigator, expand the  Motion Program folder and double-click a  CAM profile.

A graphical representation of your profile appears in the profile editor and a numeric representation appears in the profile table.


2. Insert and move points in the profile editor or table.
3. Group points into sectors in the profile table and assign curve fit order to each sector.

To add an alias to a CAM block



- In the  Project tab of the  Navigator, right-click a  CAM block, point to **Add Alias to**, and then choose a profile.

Note: Aliases correspond to CAM profiles within CAM blocks. In order to create aliases for CAM blocks, you must have previously created a CAM profile.

 **Want to know more?** In the Help Index and choose “CAM”.

Index

A

Access Control 52
 Accumulators 64
 accumulators 64
 Aliases 88
 Analog Start address 64

B

Basic CPU Redundancy 40
 Blocks
 _MAIN 51
 C 2, 71, 72
 CAM 86, 88
 LD 53
 Local Logic 81
 PLC Motion 78
 Reports 33
 Boolean Start address 64
 Build Tab 27, 28

C

C Blocks 2, 71, 72
 C Programs 2, 73, 74
 CAM Blocks 86, 88
 CAM Editor 2, 77, 86
 CAM Profiles 87
 Carrier/Base 48
 CIMPLICITY Machine Edition 1, 6, 9, 28
 CimplicityControl 1
 COM ports 24
 Communication
 Configuring 24
 Serial 24
 Companion 15
 Companion Help 18
 Configuring

Accumulators 64
 Address and Length (LD) 54, 55
 CAM Profiles 87
 Communication 24
 CPUs 26, 37
 DSM314 38, 39
 Ethernet 24
 Hardware 1, 23, 35
 Redundant Systems 42
 Scheduling 52
 Targets 22
 VersaMax Remote I/O 46

Context-Sensitive 15, 18
 CPU Redundancy Over
 Genius 40
 CPU364 24, 36
 CPU374 24

Creating

CAM Profiles 87
 IL Blocks 64
 Local Logic Blocks 81
 Reports 33
 Targets 22

CTL Bits (Local Logic) 81

D

Data Watch 14
 Diagnostics 31
 Documentation Address 22
 Downloading 27, 28
 DSM314 2, 38, 39, 77, 78, 81
 Dual HWC 22, 43, 44

E

Editing
 CAM Blocks 87

CAM Profiles 88
 IL Blocks 64
 LD Blocks 53
 Local Logic Blocks 81
 PLC Motion Blocks 78
 Ethernet 1, 22, 24, 26

F

Fault Tables 30
 Feedback Zone 14, 27, 28, 33, 34
 Finding text
 Global Search 13
 In one block 52
 Forces 59
 Functions
 IL 69
 LD 60
 fxClasses 15

G

GBC 43, 44, 49
 GE Fanuc
 PLC 1, 22
 Remote I/O 22
 Series 90™-70 Genius
 Remote I/O
 Scanner 21
 VersaMax Ethernet 21
 VersaMax Genius 21
 VersaMax Profibus 21
 Genius Bus Controller (GBC) 43, 44, 49
 Genius Redundancy 40
 Global Search 13
 Going Offline 30
 Going Online 30

H

Hardware
 Configuring 1, 23, 35
 Hardware Configuration (HWC) 2
 Help 18
 Help Index 19
 HWC 2, 35
 Hyperlinks 34

I

IL Editor 2
 Index 19
 InfoViewer 15
 InfoViewer Help 18
 Inspector 14
 Installation 4
 Instruction List (IL) 64
 Instructions
 IL 69
 LD 54, 60
 Interacting with the PLC 27
 Internet Explorer 15
 IP Address 22, 24, 25

L

LD Blocks 53
 LD Editor 2, 53
 LD Logic 2
 LLVT 83
 Local Logic 81
 Local Logic Editor 2, 77, 82
 Logic Developer - PC 2
 Logic Developer - PLC 1, 2, 5, 6,
 12, 22, 27, 29
 Logic Developer - State 2, 12, 29
 Logic Editors 51
 Logicmaster 1

M

Machine Edition 2
 Mapping a Variable 17
 Mnemonics 65
 Module Catalog 37

Motion 2
 Motion Developer 12
 Motion Programming 77

N

Navigator 14
 Network Administrator 24

O

Offline 30
 Going Offline 30
 Online 30
 Going Online 30
 Opening a Project 13
 Operands 56

P

Parameter Data (Local Logic) 81
 Parameter Editor 37, 39
 Parameters
 C Blocks 72
 C Programs 74
 PLC 1, 22
 PLC Family 22, 23
 PLC Motion Blocks 78
 PLC Motion Editor 2, 77, 78
 PLC Status 22
 Power Supply 38
 Primary HWC 42, 45
 Printing Reports 34
 Product Authorization 5
 Projects
 CIMPLICITY Machine
 Edition 9
 Creating 12
 Downloading 27
 Editing 12
 Executing 29, 67, 85
 Opening 13
 Uploading 27
 PWR321 38

Q

Quick Start 10

R

Rack Type 37
 Racks 35
 Redisplaying Reports 34
 Redundancy
 Basic CPU 40
 Configuring Systems 42
 CPU Over Genius 40, 41
 Genius 40, 41
 Redundancy Wizards dialog
 box 42, 43
 Series 90™-70 40
 Reference Address 55
 Reference View Tables 31
 Remote I/O 1, 22, 35, 47
 Remote I/O Scanner 49
 Replacing text 52
 Reports 33
 Creating 33
 Printing 34
 Redisplaying 34
 Reports Tab 33, 34
 Right-Click Menu
 HWC 36
 Target 27, 77
 Run 29
 Runtime Destination 21
 Runtime Files 27

S

SBA Node 49
 Scheduling Blocks 51
 Searching
 Global Search 13
 In one block 52
 Secondary HWC 44, 45
 Series 90™ Micro PLC 21
 Series 90™-30 PLC 21
 Series 90™-70 Genius Remote I/O
 Scanner 21, 49
 Series 90™-70 PLC 21, 40
 Slots 36
 SNP_ID 24, 26
 Status Bar 30

Stop 29
Sweep Time 22
Synchronizing 9, 45
System Requirements 3

T

Table of Contents 20
Targets 21
 Configuring 22
 Creating 22
 Downloading 28
 Remote I/O Scanner 49
 Right-Click Menu 27, 77
 Uploading 29

 Validating 27
Templates 12
Toolchest 15
Tools 14

U

Uploading 27, 29
URL 22
User Programs 73, 74

V

Validating a Target 27
Variables 16
 Mapping 17

VersaMax Ethernet 21
VersaMax Genius 21
VersaMax Nano/ Micro PLC 21
VersaMax PLC 21
VersaMax Profibus 21
VersaMax Remote I/O 46
VersaPro 1
View 2, 12

W

Windows Explorer 14
Word-for-Word Changes 58, 68