

GFK-1175
New In Stock!
GE Fanuc Manuals

<http://www.pdfsupply.com/automation/ge-fanuc-manuals/field-control->

[info/GFK-1175](http://www.pdfsupply.com/automation/ge-fanuc-manuals/field-control-info/GFK-1175)
field-control-info
1-919-535-3180

Field Control Distributed I/O & Control System FIP Bus Interface
Unit

www.pdfsupply.com

Email: sales@pdfsupply.com

GFK-1175
New In Stock!
~~GE Fanuc Manuals~~

<http://www.pdfsupply.com/automation/ge-fanuc-manuals/field-control->

[info/GFK-1175](http://www.pdfsupply.com/automation/ge-fanuc-manuals/field-control-info/GFK-1175)
field-control-info

1-919-535-3180

Field Control Distributed I/O & Control System FIP Bus Interface
Unit

www.pdfsupply.com

Email: sales@pdfsupply.com



GE Fanuc Automation

Programmable Control Products

*Field Control™
Distributed I/O and Control System*

*FIP Bus Interface Unit
User's Manual*

GFK1175

June 1995

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.


Alarm Master	Field Control	Modelmaster	Series One
CIMPLICITY	GEnet	ProLoop	Series Six
CIMPLICITY	Genius	PROMACRO	Series Three
PowerTRAC	Genius PowerTRAC	Series Five	VuMaster
CIMPLICITY 90-ADS	Helpmate	Series 90	Workmaster
CIMSTAR	Logicmaster		

Chapter 1

Introduction

This chapter introduces Field Control™ modules, the FIP Bus Interface Unit, and other equipment that may be used with the Bus Interface Unit. It will help you locate more information in other Field Control and FIP documents.

Overview



Field Control is a family of highly-modular distributed I/O and control products. They are suitable for use in a wide range of host architectures.

The heart of the Field Control system is the Bus Interface Unit. The Bus Interface Unit provides intelligent processing, I/O scanning, and feature configuration for a group of up to eight I/O modules. Together, the Bus Interface Unit and its modules make up a Field Control station (see the illustration, left).

The Bus Interface Unit and I/O modules are enclosed in sturdy, compact aluminum housings. The Bus Interface Unit and I/O modules bolt securely to separate Terminal Blocks, which provide all field wiring terminals. The I/O Terminal blocks are generic and allow different I/O module types to be mounted on the same base. I/O Terminal Blocks are available with either box-type or barrier-type terminals. All Terminal Blocks must be mounted on a DIN rail. The DIN rail, which serves as an integral part of the grounding system, can also be mounted on a panel.

Field Control Features


Features and benefits of Field Control include:

- wiring savings
- better up time
- easy installation and maintenance
- spare parts savings
- low cost
- feature flexibility
- open architecture / adaptable to a variety of networks
- distributed I/O
- small, compact I/O modules with generic terminal wiring bases
- DIN rail mounted

Field Control Modules

There are three basic types of Field Control modules:

- **Bus Interface Unit.** The illustration below shows a FIP Bus Interface Unit.
- **I/O modules**
- **Terminal Blocks:**
 - Bus Interface Unit Terminal Block.
 - I/O Terminal Blocks, each of which accommodates two I/O modules.
 - Auxiliary Terminal Blocks. These optional terminal strips can be connected to the side of an I/O Terminal Block if extra common terminals are needed.



FIP Bus Interface Unit

The FIP Bus Interface Unit interfaces Field Control I/O modules to a FIP bus.

The intelligent processing capabilities of the FIP Bus Interface Unit allow the configuration of features such as fault reporting, selectable input and output defaults, analog scaling and analog range selection for the modules in the station. In addition, the FIP Bus Interface Unit performs diagnostic checks on itself and its I/O modules, and relays diagnostic information to the host (if configured for fault reporting) and to a Hand-held Programmer.

The Bus Interface Unit mounts on a Bus Interface Unit Terminal Block. The Bus Interface Unit can be removed and replaced if necessary without removing the wiring or reconfiguring the I/O station.

Bus Interface Unit Terminal Block

The Bus Interface Unit Terminal Block provides connections for power wiring and single or dual communications cables. The Bus Interface Unit Terminal Block stores the configuration parameters selected for the station.

I/O Modules

Field Control I/O Modules are available in many types to suit a wide range of application needs. Modules can be installed and removed without disturbing field wiring. One or two I/O modules may be mounted on an I/O Terminal Block.

I/O Terminal Blocks and Auxiliary I/O Terminal Blocks

An I/O Terminal Block provides mounting, electrical, and field wiring connections. Each half of the I/O Terminal Block can be mechanically keyed to accept only an I/O module of a specific type. Auxiliary I/O Terminal Blocks can be easily attached to an I/O Terminal Block. They provide the extra connections needed for analog and high-density discrete modules.

For more information, please refer to:

Chapter 2: Installation, which explains wiring to the Bus Interface Unit, and explains how to install the Bus Interface Unit module on the Field Terminal Block.


Chapter 3: Operation, which explains how the FIP Bus Interface Unit services I/O.

The ***Field Control I/O Modules User's Manual***, which describes I/O modules and I/O Terminal Blocks. This manual also explains module installation and field wiring.

Locations for Field Control

The FIP Bus Interface Unit and Field Control I/O modules can be located on equipment, in junction boxes, inside panels, behind operator stations, and in other locations where space is limited. The area should be clean, free of airborne contaminants, and provide adequate cooling. Field Control modules can be installed in NEMA enclosures. The enclosure can be as little as 4 inches (10.16 cm) deep. A 35mm x 7.5mm DIN rail is required.

The Bus Interface Unit Terminal Block and up to four I/O Terminal Blocks are grouped together using the connection cables provided. All of the I/O Terminal Blocks in a group must be connected either before or after the Bus Interface Unit. A Bus Interface Unit may not be connected between I/O Terminal Blocks.



46405

Terminal Blocks can be mounted in any orientation without derating the modules' temperature specification.

Field Control Environmental Specifications

- Vibration** Modules perform well where vibration is a factor. Modules are installed on a panel-mounted DIN rail using the clamp supplied, and with the panel-mounting feet secured. For information about vibration standards, please see the *Conformance to Standards* document (GFK-1179).

- Noise** Modules are resistant to noise levels found in most industrial applications when installed according to accepted practices, including proper separation of wiring by voltage and power level. Modules must be installed on a conductive (unpainted) DIN rail. The DIN rail is an integral part of the grounding system.

Modules are tested to the specifications listed in the *Conformance to Standards* document (GFK-1179).

- Temperature** Modules operate reliably in ambient air temperatures from 0C (32F) up to 55C (131F).

Storage temperatures are -40C (-40F) to +85C (185F).

- Humidity** 5% to 95%, non-condensing.

For information about installing Field Control modules, please see:


Chapter 2 of this manual. It describes installation and wiring for the Bus Interface Unit module and terminal block.

Chapter 2 of the *Field Control I/O Modules User's Manual*. It summarizes installation instructions for modules and terminal blocks. Detailed installation instructions are also packed with individual Field Control modules.

The individual module datasheets included in the *Field Control I/O Modules User's Manual*, which provide specific module wiring information.

FIP Bus Interface Unit

The FIP Bus Interface Unit is a small, rugged, intelligent module with a sturdy aluminum housing. The module has four status LEDs and a connector for a Hand-held Programmer.



The Bus Interface Unit requires an external source of 24 VDC power.

The BIU's internal power supply provides power for the operation of the BIU itself, and logic power for the I/O modules connected to it.

It mounts on a separate terminal block, to which it and all field wiring are attached. The configuration is stored in non-volatile memory located in the terminal block.

The Bus Interface Unit has a replaceable 1A, 5x20mm 250VAC slow-blow fuse on the input power lines. The fuse can be changed without disturbing the wiring of any other modules.

Bus Interface Unit Power Supply

The 24 VDC power supply in the Bus Interface Unit provides power for the Bus Interface Unit itself and logic power for all I/O modules that may potentially be installed at that station.


External power must be supplied for input and output devices.

The BIU power supply is not damaged by either of the following:

- Reversing input voltage on terminals 1 and 2.
- *Temporary* overcurrent conditions on the 6.5 VDC output.


Timing

The Bus Interface Unit provides power to all I/O modules that are installed at the station. I/O module operation is governed by a System Reset signal to ensure controlled operation during the power up and shut down processes. As shown in the timing diagram below, momentary power losses of less than 10 milliseconds do not affect I/O module operation; however, longer power losses generate a Reset for all system I/O modules.



Calculating Input Power Requirements for a Bus Interface Unit

The chart below shows typical input power requirements for the 24 VDC power supply.



Note

Start-up surge at full load is 15–50 Amps for 3 milliseconds (maximum).

To determine specific system requirements:

- Determine total output load from typical specifications listed for individual modules.
- Use the graph above to determine average input power.
- Divide the input power by the operating source voltage to determine the input current requirements.
- Use the lowest input voltage to determine the maximum input current.
- Allow for startup surge current requirements. Startup surge current levels are a function of source impedance and, therefore, are installation-dependent. Startup surge currents can vary between 25A and 50A for approximately 3mS.
- Allow margins (10% to 20%) for variations.


Bus Interface Unit Terminal Block

The Bus Interface Unit provides terminals for power and ground connections. Maximum wire size is AWG #14. (avg 2.0690mm² cross-section).

The Bus Interface Unit Terminal Block also has two connectors for attachment to a single or dual FIP bus.

A connecting cable is provided with each I/O Terminal Block. It is used to connect the Bus Interface Unit Terminal Block to the first I/O Terminal Block. The same type of cable interconnects subsequent I/O Terminal Blocks. The cable has molded connectors that are keyed to assure proper orientation.

The Bus Interface Unit Terminal Block stores the configuration parameters for the station. The Bus Interface Unit can be removed without removing the wiring or reconfiguring the station.



Specifications for the Bus Interface Unit terminal block are listed on page 2-6. Wiring information is in chapter 3.

Bus Interface Unit Functional Specifications

<p>Bus Interface Unit:</p> <p>Reliability</p> <p>Power Supply Input</p> <p style="padding-left: 20px;">Nominal Rated Voltage</p> <p style="padding-left: 20px;">Voltage Range</p> <p style="padding-left: 20px;">Power</p> <p style="padding-left: 20px;">Inrush Current</p> <p>Power Supply Output</p> <p style="padding-left: 20px;">To CPU and communications:</p> <p style="padding-left: 20px;">To Hand-held Programmer:</p> <p style="padding-left: 20px;">To I/O modules:</p> <p>Holdup Time</p>	<p>More than 200,000 hours operation MTBF, calculated</p> <p>24 VDC</p> <p>18 VDC to 30 VDC</p> <p>16.8 Watts maximum at full load (nominal voltage)</p> <p>15-50 Amps peak, 3 mS maximum (see note)</p> <p>5.0 VDC +/- 3.5%</p> <p>Current required: 0 to 0.42 Amp (0.40 Amp typical)</p> <p>6.5VDC +/-5%</p> <p>Current required: 0 to 0.193 Amp maximum with Hand-held Programmer (.013 Amp typical)</p> <p>85 mWatt typical, 1.25 Watt maximum</p> <p>6.5 VDC ±5%</p> <p>1.0 Amp maximum</p> <p>10mS maximum</p>
<p>Bus Interface Unit Terminal Block:</p> <p>Power Requirements</p> <p>Reliability</p>	<p>16mA maximum</p> <p>More than 600,000 hours operation MTBF, calculated</p>

For information about I/O modules, please see the *Field Control I/O Modules User's Manual*, (GFK-0926).


Note

Inrush current is installation dependent. See page 1-8.

For information about installing I/O modules, see the *Field Control I/O Modules User's Manual*.

Hand-held Programmer

The Hand-held Programmer provides a convenient portable operator interface to the Bus Interface Unit and I/O modules.



The Hand-held Programmer can be used to monitor, force, and unforce I/O, and to display diagnostics.

For more information, please see:

Chapter 4, Hand-held Programmer Functions.

The *Hand-held Programmer Manual* (GFK-0402) for basic HHP operating instructions.

Series 90-70 PLC: Requirements

For a FIP Bus Interface Unit used in a Series 90-70 PLC system, the following are required:

- Series 90-70 CPU version 6 or later.
- Logicmaster™ 90-70 programming and configuration software release 6 or later.
- Series 90-70 FIP Bus Controller

Configuration

The FIP Field Control I/O Station may be configured in two ways.

- temporarily with a Hand-held Programmer.
- over the FIP network.

Hand-held Programmer Configuration

A Hand-held Programmer can be used to temporarily configure I/O modules so I/O data can be monitored, forced and unforced, before the Bus Interface Unit is operational on the FIP network.

For more information about this type of configuration see **Chapter 4, Hand-held Programmer Functions**.

Network Configuration

A Network Configuration must be received before the Bus Interface Unit can exchange I/O data on the network. Until it has a valid configuration, the Bus Interface Unit is only capable of identifying itself on the network, then accepting the configuration supplied.

For more information about this type of configuration see the ***FIP Bus Controller User's Manual*** (GFK-1038).

Chapter 2

Installation

This chapter describes installation procedures for the Bus Interface Unit.

- Preinstallation Check
- Static Protection
- Removing the Bus Interface Unit from the Terminal Block
- Installing the DIN Rail
- Installing the Bus Interface Unit Terminal Block on the DIN Rail
- Installing the Cables Between Terminal Blocks
- Setting the BIU DIP Switches
- Installing the Bus Interface Unit on the Terminal Block
- System Wiring Guidelines
- System Grounding
- Power Wiring to the Bus Interface Unit
- Connecting the Communications Bus
- Observing the LEDs
- Removing/Replacing the Bus Interface Unit Fuse
- Removing the Bus Interface Unit Terminal Block from the DIN Rail

Preinstallation Check

Carefully inspect all shipping containers for damage during shipping. If any part of the system is damaged, notify the carrier immediately. The damaged shipping container should be saved as evidence for inspection by the carrier.

As the consignee, it is your responsibility to register a claim with the carrier for damage incurred during shipment. However, GE Fanuc will fully cooperate with you, should such action be necessary.

After unpacking the Field Control modules and other equipment, record all serial numbers. Serial numbers are required if you should need to contact Product Service during the warranty period of the equipment.

All shipping containers and all packing material should be saved should it be necessary to transport or ship any part of the system.

Static Protection

The Bus Interface Unit has CMOS components that are susceptible to static damage. *Use proper static handling techniques when handling this module.*

Removing the Bus Interface Unit from the Terminal Block

The Bus Interface Unit is shipped pre-installed on the BIU Terminal Block.

Remove it to set the BIU DIP switches and to install the connector cable to the first I/O Terminal Block.

- 1. Loosen the Bus Interface Unit retaining screws.


Caution

Be sure screws are fully disengaged. Attempting to remove the module with screw(s) partially engaged may damage it.

- 2. Pull the Bus Interface Unit module straight away from the Terminal Block.

Caution


Do not tilt the Bus Interface Unit to remove it. Attempting to remove the Bus Interface Unit at an angle may damage it.



Installing the DIN Rail


AllField Control Terminal Blocks must be mounted on a 7.5mm x 35mm DIN rail. The rail must have a conductive (unpainted) finish for proper grounding. For best vibration resistance, the DIN rail should be installed on a panel using screws spaced approximately 6 inches (5.24cm) apart. When using multiple rail sections, be sure they are properly aligned. Mount the DIN rail at least 4.25 inches (10.80 cm) from any wireway or other obstruction *on the wiring side of the Bus Interface Unit*. Allow more space if the wiring for I/O modules is very stiff.

Drill mounting holes for the BIU Terminal Block as shown below. Allow a small tolerance between the top and bottom of adjacent terminal blocks.




Installing the Bus Interface Unit Terminal Block on the DIN Rail

1. Tilt the Bus Interface Unit Terminal Block and position it over the rail, as shown below left, catching the rail behind the tabs in the terminal block.
2. Pivot the terminal block downward until the spring-loaded DIN rail latches in the terminal block click into place.



3. Tighten the DIN rail clamp screw (see below left). Maximum recommended torque is 8 in./lbs to 10 in./lbs.




4. Secure the terminal block to the panel with 3/8 inch (9.525mm) #6 screws (not supplied) through the mounting ears.

Installing the Cables Between Terminal Blocks

Before installing modules on their terminal blocks, install the connecting cable(s) between terminal blocks. A short connecting cable, as illustrated below, is supplied with each I/O Terminal Block. A set of three connecting cables is available as renewal part number IC670CBL001. Optional 21 inch (0.53 meter) cable is also available (only one longer cable can be used per I/O station).

The illustration below shows cable connection between a Bus Interface Unit terminal block and an I/O Terminal Block. Make connections between I/O Terminal Blocks in the same manner. The connectors are keyed to assure proper installation.


After installing the cable, be sure it is firmly seated on both connectors.



Setting the BIU DIP Switches

The DIP switches on the Bus Interface Unit select FIP or World FIP protocol and establish the BIU's Station ID (network address).

There are two DIP switch packs located inside the main portion of the BIU.



Switch Positions

Switch positions are numbered 0 through 7 *on the circuit board*.




Switch 7 selects FIP or World FIP protocol, as shown in the table below. Switches 0 through 6 represent a Station ID from 0 to 127 (decimal).

Switch 7	Switches 6 to 0							Address Represented
7	6	5	4	3	2	1	0	
" FIP = 1	#	#	#	#	#	#	#	0
# World FIP = 0	"	#	#	#	#	#	#	1

	"	"	"	"	"	"	"	127

Installing the Bus Interface Unit on the Terminal Block



1. Before installing a new Bus Interface Unit, remove the cable slot knockout on the end of the module that will cover the connecting cable. It can be removed with pliers, or by pressing *out* from inside the module housing.
2. To install Bus Interface Unit on the terminal block, position the module so that the cable slot in the module housing is over the connecting cable. Press the module down firmly.

Caution

Do not exert excessive force; it may damage the equipment.

3. If unusual resistance is met, remove the Bus Interface Unit. If power is applied, **DO NOT TOUCH THE CONNECTOR PINS!** Inspect the Terminal Block, and the connectors on the Terminal Block and on the Bus Interface Unit. Remove any obstacles and reinsert the Bus Interface Unit.
4. After placing the Bus Interface Unit onto the terminal block, tighten its screws to secure it. Maximum recommended torque is 9in/lbs.

System Wiring Guidelines

Four types of wiring may be encountered in a typical factory installation:

1. Power wiring – the plant power distribution, and high power loads such as high horse-power motors. These circuits may be rated from tens to thousands of KVA at 220 VAC or higher.
2. Control wiring – usually either low voltage DC or 120 VAC of limited energy rating. Examples are wiring to start/stop switches, contactor coils, and machine limit switches. This is generally the interface level of the Genius discrete I/O.
3. Analog wiring – transducer outputs and analog control voltages. This is the interface level to Genius I/O analog blocks.
4. Communications and signal wiring – the communications network that ties everything together, including computer LANs, MAP, and FIP and Genius busses.

These four types of wiring should be separated as much as possible to reduce the hazards from insulation failure, miswiring, and interaction (noise) between signals. A typical PLC system may require some mixing of the latter three types of wiring, particularly in cramped areas inside motor control centers and on control panels.

In general, it is acceptable to mix the communications bus cable with the I/O wiring from the blocks, as well as associated control level wiring. All noise pickup is cumulative, depending on both the spacing between wires, and the distance span they run together. I/O wires and communications bus cable can be placed randomly in a wiring trough for lengths of up to 50 feet. If wiring is cord-tied (harnessed), do not include the bus cable in the harness, since binding wires tightly together increases the coupling and mechanical stress that can damage the relatively soft insulation of some serial cable types.


Wiring which is external to equipment, and in cable trays, should be separated following NEC practices.

Installing Additional Suppression

It is possible some installations might exceed the surge immunity capabilities of the Bus Interface Unit. This is most likely in outdoor installations or where the power source is from another building or ground system. It is prudent to provide local transient protection.

System Grounding

All components of a control system and the devices it controls must be properly grounded. Ground conductors should be connected in a star fashion, with all branches routed to a central earth ground point as shown below. This ensures that no ground conductor carries current from any other branch.




Each Field Control Terminal Block has a chassis ground terminal for safety and noise protection. This terminal should be connected to the conductive mounting panel with a 4-inch maximum length of AWG #14 (avg 2.1mm²) wire. Use hardware such as star washers to ensure ground integrity.

The control panel and enclosure should also be bonded to the plant system ground per code. Inadequate grounding may compromise system integrity in the presence of power switching transients and surges.

Power Wiring to the Bus Interface Unit

1. Connect an appropriate source of 24 VDC (nominal) to the Bus Interface Unit Terminal Block as shown below. **Do not apply power yet.**




2. Connect the ground terminal to chassis ground using an AWG #14 (avg 2.1mm²) stranded wire.

Connecting the Communications Bus

For information about cable type, termination, grounding, and connections between devices, please refer to the *FIP Bus Controller User's Manual* (GFK-1038).

Attach FIP bus cable(s) to the connectors on the front of the Bus Interface Unit. When installed in a single media or simplex configuration, either connector may be used.


46508



Note: If only one FIP bus is used, it is recommended that you cover the unused FIP bus connector with an anti-static cap.

Pin Assignments for the FIP Bus Connectors

The diagram below shows pin assignments for both FIP bus connectors on the front of the BIU.




46509

Observing the LEDs

When power is applied, the LEDs on the BIU indicate operating and communications status.

46510



The top 2 LEDs indicate module health. The bottom 4 LEDs indicate communications activity on the FIP bus. Two LEDs are dedicated to each of the two FIP channels.

- MODULE OK** – Shows the status of the BIU. This LED blinks during power-up diagnostics and should remain on as long as power is applied to the BIU.
- RUN** – Shows whether the BIU is actively receiving outputs from the network.
- CARRIER DETECT** – A Carrier Detect LED is ON when the BIU is detecting a carrier signal on the FIP bus attached to that channel.
- TRANSMIT ENABLE** – A Transmit Enable LED is ON when the BIU transmits data on the FIP bus attached to that channel.

Removing/Replacing the Bus Interface Unit Fuse

If all the Bus Interface Unit LEDs go off, it may be necessary to replace its fuse. The fuse can be removed without disturbing any other parts of the station or wiring.

To check the fuse, remove power from the station.

Fully loosen the retaining screws in the Bus Interface Unit and carefully remove it from the Terminal Block. Do not tilt the module during removal.


Caution

Avoid touching the exposed wiring on the Terminal Block when removing the Bus Interface Unit.

Caution

Electrostatic discharge can damage the module when it is not installed on a Terminal Block. Always observe normal ESD protection practices (for example, use a grounding strap) when handling an un-installed module.

The fuse location is shown below. Visually inspect the fuse to see whether it has blown.




To remove the fuse from the holder, carefully pry it upward. Take care not to damage any components in the module. Place the new fuse in position and press it into the holder.

The fuse should be a 1A, 5x20mm 250VAC slow-blow type.

Reinstall the Bus Interface Unit on the BIU Terminal Block.

Removing the Bus Interface Unit Terminal Block from the DIN Rail

1. Loosen the clamp screw.
2. Remove the panel-mounting screws.
3. Insert a small flat-blade screwdriver into the upper latch and pry it outward. Then, pull up gently on the top of the terminal block to disengage the upper latch from the rail.



4. Keep gently pulling the top of the terminal block away from the rail. Insert the screwdriver into the lower latch and pry it outward to free the terminal block.

Chapter 3

Operation


This chapter explains how a Bus Interface Unit interacts with the modules in its I/O Station, how it stores data, and how it exchanges data with the system host.

Operation

The primary runtime operations of the Bus Interface Unit are to accept data from the FIP bus and pass this to the corresponding output modules and to acquire updated input data for transmission onto the FIP bus.

If a problem occurs (or is corrected) with any module or circuit, it is included in the status information regularly transmitted by the Bus Interface Unit. Such module problems do not affect operation of the Bus Interface Unit or its communications on the network.

Operating Modes of the Bus Interface Unit



The Bus Interface Unit can operate in the following modes:


- Idle Mode
- Ready Mode
- Run Mode

How Communications Affect Operating Mode

The operating mode of the Bus Interface Unit depends on whether or not it is communicating with the FIP network.

- A. If it is communicating with the FIP network, the Bus Interface Unit may be commanded by the network controller to operate in Idle, Ready, or Run mode.
- B. If a FIP network is not present, the Bus Interface Unit remains in Idle mode at powerup.
- C. If a FIP network is present but communications between the Bus Interface Unit and the network controller have been lost, the Bus Interface Unit returns from Run mode back to Ready mode.

Idle Mode



In Idle mode, the Bus Interface Unit can indicate its presence on the FIP bus, but it cannot exchange I/O data.

The Bus Interface Unit is in Idle mode after it is powered up but when no configuration or mode change commands have been received from the network. During normal operation, the Bus Interface Unit is only in Idle mode during the first few seconds after powerup. If a FIP network controller is not present, the Bus Interface Unit remains in Idle mode.


In Idle mode:

- the Bus Interface Unit scans I/O modules for identification information, input data and output data. Unless forced, outputs remain at their programmed default states or hold their last states as configured. If forced, the force values are applied.
- the I/O default data and the force conditions are recovered from non-volatile memory for later use.
- all I/O validator data is set to “invalid.”
- a Hand-held Programmer can be used to monitor I/O and input module configurations if no configuration is available from the network.
- The Bus Interface Unit can receive a system configuration from the FIP network. No forcing via FIP messages is permitted.

After receiving a system-level configuration the Bus Interface Unit can be commanded (from the network) to go to Ready mode.

Ready Mode

The Bus Interface Unit goes to Ready mode when a system-level configuration has been received and enabled.



In Ready mode:


- the Bus Interface Unit waits for permission to enter Run mode from the FIP network controller.
- a Hand-held Programmer can be used to monitor I/O and module configurations.
- configuration can NOT be changed by a Hand-held Programmer.
- the Bus Interface Unit scans I/O in accordance with the configuration it received from the FIP network.
- the Bus Interface Unit accepts forcing information from the network.

The Bus Interface Unit can be commanded (from the network) to go to Idle mode for reconfiguration or it may be commanded to go to Run mode.

Run Mode

In Ready mode, when the Bus Interface Unit receives a command to do so, it goes to Run mode.

In Run mode:



- all configured modules are operational
- data is communicated to and from the FIP network.
- the Bus Interface Unit scans I/O in accordance with the configuration it received from the FIP network.
- the Bus Interface Unit generates and observes validators.
- the Bus Interface Unit can communicate fully on the FIP network.
- configuration changes are not permitted.
- HHP use is not permitted in Run (Locked) mode.

The mode changes back to Ready upon command from the network or if the Bus Interface Unit loses communications.

Run Unlocked Mode

Run Unlocked mode is the same as described above, except that the Bus Interface Unit does not check refreshment and promptness status in Run Unlocked mode.

I/O Data

The Bus Interface Unit stores I/O data, as well as additional data representing forced conditions and “validator” status, in separate memory areas.

DataDescription	Data Type Displayed on HHP	Series 90-70 PLC Data Type
discrete input states	I	%I
discrete output states	Q	%Q
analog input values	AI	%AI
analog output values	AQ	%AQ
discrete input validators		Fault/NoFault Contacts
output validators		
analog input validators		
analog output validators		

In the Bus Interface Unit, the I/O state and validator tables contain the input and output data.

- If the Bus Interface Unit detects a problem while reading a module’s inputs, it sets to 1 (invalid) all Input Validators for that module.
- If output validators for outputs received from the network are “invalid” (1) those outputs will be defaulted or hold last state.

Displaying Data with a Hand-held Programmer

The Hand-held Programmer can read data directly from the Bus Interface Unit. If the Bus Interface Unit is in Idle or Ready mode, the Hand-held Programmer can also force the states of I/O data.

Discrete Inputs

The Bus Interface Unit has the following discrete input tables:

I	discrete input states
IV	discrete input validators
IF	force applied: discrete inputs
IFV	force applied: discrete input validators

The Bus Interface Unit processes input data as described below.

1. The Bus Interface Unit scans input modules in the I/O Nest and then places discrete input data in its discrete input table.

Example:

The Bus Interface Unit reads the inputs configured to use I0001 through I0008 during its input scan. It places the data into its discrete input table:

I0001	I0008								
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>1</td><td>0</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td> </tr> </table>		1	0	0	1	0	1	0	0
1	0	0	1	0	1	0	0		

2. If the Bus Interface Unit detects a module fault while reading the input data, it defaults all inputs for that module to the configured off or last state, and marks them as “invalid” by setting the input validator (IV) locations associated with those inputs.

Example:

If the module supplying inputs I0001 through I0008 is configured to default inputs OFF, and the module is subsequently removed, the Bus Interface Unit sets its inputs OFF and also sets the corresponding input validator data:

I0001	I0008									
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> </table>		0	0	0	0	0	0	0	0	Inputs set to OFF
0	0	0	0	0	0	0	0			
IV0001	IV0008									
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td> </tr> </table>		1	1	1	1	1	1	1	1	Input validators set to “invalid”
1	1	1	1	1	1	1	1			

3. If the Bus Interface Unit is in any Idle or Ready mode, inputs may be forced. The Bus Interface Unit sets the corresponding inputs in the input table. When a force is removed, the input table displays the normal data following the next I/O scan.

Example:

The HHP is used to force input I0008 to 1.

I0001	I0008									
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>1</td><td>0</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td> </tr> </table>		1	0	0	1	0	1	0	0	Input Data before forcing
1	0	0	1	0	1	0	0			
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>1</td><td>0</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td style="background-color: #cccccc;">1</td> </tr> </table>		1	0	0	1	0	1	0	1	Input Data after forcing
1	0	0	1	0	1	0	1			

- When you force the state of a point, the Bus Interface Unit forces the corresponding validator (IVF) to 0 (valid).

Example:


When the HHP forces input I0008, the input validator is also forced.

I0001				I0008				
1	0	0	1	0	1	0	0	Input Data before forcing
1	0	0	1	0	1	0	1	Input Data after forcing
1	1	1	1	1	1	1	0	Validator Data after forcing

The other bits retain their current states. In this example, the other bits happen to all be 1s.

Input Data Sent on the Bus

The Bus Interface Unit treats the data acquired from each Input or Input/Output module as an “application variable.” It combines these (input) application variables into one or more Communications Variables (COMVs). It periodically transmits these COMVs on the FIP Network.



The Bus Interface Unit honors requests for input data even when the data is invalid (e.g. the corresponding input module has been removed). By monitoring the validity data, the host can know whether the data it receives from the Bus Interface Unit is real or defaulted input data.


Discrete Outputs

The Bus Interface Unit has the following discrete output tables:

Q	discrete output states
QV	discrete output validators
QF	force applied: discrete outputs
QVF	force applied: discrete output validators

The Bus Interface Unit processes output data as described below.

1. The Bus Interface Unit periodically receives Communications Variables (COMVs) containing discrete output data. The content of these COMVs may depend on the system host. In a Series 90 PLC system, discrete output COMVs consist of Q data (application variables) and QV data (validity qualifiers).



2. The Bus Interface Unit places the output data into its discrete output table.

Example:

The Bus Interface Unit receives output data from the host, including outputs Q0009 through Q0016. It places those outputs into its discrete output table as illustrated below:

Q0009				Q0016			
0	0	1	1	0	1	1	1

3. The Bus Interface Unit checks the corresponding validity data to determine whether or not the output data received from the host is valid.

The specific way output validators are set may depend on the system host. In a Series 90-70 PLC system, the PLC bus controller sets the output validators to invalid if it doesn't receive output communications from the CPU. The Bus Interface Unit also sets output validators if it doesn't receive output data from the FIP bus during a specified period of time.

If an output validator is set to invalid, the Bus Interface Unit discards the actual output data and sets the corresponding output to the configured default states or holds their last state (as configured).

Example:

If the host stopped sending outputs, the Bus Interface Unit could set all discrete outputs to off (as shown here) or to their last state, and also set the corresponding output validator data:

Q0009		Q0016																	
<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> </tr> </table>	0	0	0	0	0	0	0	0		<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> </tr> </table>	1	1	1	1	1	1	1	1	<p>Outputs set to OFF</p> <p>Output validators set to "invalid"</p>
0	0	0	0	0	0	0	0												
1	1	1	1	1	1	1	1												
QV0009		QV0016																	

4. The Bus Interface Unit passes outputs (either actual outputs or outputs that are defaulted) to the output modules. The output scan occurs after the input scan.
5. If the Bus Interface Unit is in any Idle or Ready mode, outputs may be forced from the HHP. The Bus Interface Unit sets the corresponding outputs in the output force (QF) table. The forced state becomes the state of the output circuit.

Example:

The HHP is used to force output Q0012 to 0.

Q0009		Q0016																	
<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> </tr> </table>	0	0	1	1	0	1	1	1		<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px; background-color: #cccccc;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">1</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">1</td> </tr> </table>	1	1	1	0	0	1	0	1	<p>Output Data before forcing</p> <p>Output Data after forcing</p>
0	0	1	1	0	1	1	1												
1	1	1	0	0	1	0	1												

When a force is removed, the data in the corresponding I/O table displays the normal data following the next I/O scan. Outputs retain an up-to-date processed value, which is used whenever the forced value is removed.

Analog Inputs

The Bus Interface Unit has the following analog input tables.

AI	analoginput values
AIV	analoginputvalidators
AIF	force applied: analog inputs
AIVF	force applied: analoginput validators

The Bus Interface Unit processes analog input data as described below (analog input modules filter data locally, so the data is already filtered when the Bus Interface Unit reads it.)

1. The Bus Interface Unit scans analog input modules in the I/O Nest and places analog input data in its analog input table.

Example:

During the analog input scan, the Bus Interface Unit reads the inputs configured to use AI001 through AI004. It places the inputs into its analog input table:

AI001	57143
AI002	16385
AI003	36884
AI004	1141

2. If the Bus Interface Unit detects a module fault while reading the input data, it defaults all inputs associated with that module to their default/hold last state values, and marks them as “invalid” by setting the AIV locations associated with those inputs.

Example:

If the module supplying inputs AI001 through AI004 were removed and the module were configured for Hold Last State, the Bus Interface Unit would hold the inputs for that module to their last values, and set the corresponding validators to invalid (1).

Analog Input Data		Validator Status	
AI001	57143	AIV001	1
AI002	16385	AIV002	1
AI003	36884	AIV003	1
AI004	1141	AIV004	1

1 = invalid

3. Analog inputs may be forced. The Bus Interface Unit sets the corresponding inputs in the analog input table, which also contains the current states of unforced inputs. When a force is removed, the input table displays the normal data following the next I/O scan.

Example:

The HHP is used to force analog input AI002 to a different value. The forced value replaces the actual value in the analog input table:

	Analog Input Data before forcing	Analog Input Data after forcing
AI001	57143	57143
AI002	16385	500
AI003	36884	36884
AI004	1141	1141

Input data which requires multiple samples for its processing (e.g. filtered inputs) maintains an up-to-date processed value even while forced.

4. When you force the state of a point, the Bus Interface Unit also forces the corresponding validator (IVF) to 0.


Example:

When the HHP forces input AI002 its input validator is also forced.

	Analog Input Data before forcing	Analog Input Data after forcing	Validator Status
AI001	57143	57143	1
AI002	16385	500	0
AI003	36884	36884	1
AI004	1141	1141	1

Analog Input Data Sent on the Bus

The Bus Interface Unit combines analog input data into one or more Communications Variables (COMVs). It periodically transmits these COMVs on the Network.



The Bus Interface Unit honors requests for input data even when the data is invalid (e.g. the corresponding input module has been removed). By monitoring the validity data, the host can know whether the data it receives from the Bus Interface Unit is real or defaulted input data.

AnalogOutputs


The Bus Interface Unit has the following analog output tables.

AQ	analog output values
AQV	analog output validators
AQF	force applied: analog outputs
AQVF	force applied: analog output validators

The Bus Interface Unit processes analog output data as described below.

1. The Bus Interface Unit periodically receives Communications Variables (COMVs) containing analog output data.

The content of these COMVs may depend on the system host. In a Series 90 PLC system, analog output COMVs consist of AQ data (application variables) and AQV data (validity qualifiers).



2. The Bus Interface Unit places the output data into its Analog Output table.

Example:

The Bus Interface Unit receives output data from the host, including outputs AQ005 through AQ008. It places those outputs into its AQ data table as illustrated below:

AQ005	114
AQ006	72
AQ007	106
AQ008	93

3. The Bus Interface Unit checks the corresponding validity data to determine whether or not the output data received from the host is valid.

The specific way output validators are set may depend on the system host. In a Series 90-70 PLC system, for example, the PLC bus controller sets the output validators to invalid if it doesn't receive output communications from the CPU. The Bus Interface Unit also sets output validators if it doesn't receive output data from the FIP bus during a specified period of time.

- 4. If output validators are set to invalid the Bus Interface Unit defaults the output data to a configured value or holds its last state, as configured.

Example:

If the host stopped sending outputs, the Bus Interface Unit would default or hold all analog outputs at their last values and also set the corresponding output validator data:

Analog Output Data		Validator Status		
AQ005	114	AQV005	1	1 = invalid
AQ006	72	AQV006	1	
AQ007	106	AQV007	1	
AQ008	93	AQV008	1	


Diagnostics

The Bus Interface Unit provides status information for each I/O module in the I/O Nest. If a fault occurs, the fault is logged and the corresponding fault contact is activated. It remains activated only while the fault is in effect. After the condition that caused the fault is corrected, the Bus Interface Unit deactivates the corresponding fault contact and resumes normal operation of the affected circuit(s).

Status Data Transmitted by the Bus Interface Unit

The Bus Interface Unit periodically transmits status information as a separate Communications Variable.

46514




If a problem occurs (or is corrected) with any module or circuit, it is included in this status information. Such module problems do not affect the operation of the Bus Interface Unit or its communications on the network.

Bus Interface Unit Status Data Format


The format of the status (IOSTAT) COMV sent by the Bus Interface Unit is shown below.

Offset (Byte #)	Content	Description
0	1	Bus Interface Unit Identification
1	0	
2, 3	0 to 65535	Version number
4	00 = Non-operational fault 01 = Operational: Idle 02 = Operational: Ready 03 = Operational: Running Locked 04 = Operational: Running Unlocked 05 = User Fault	Operating mode (hex)
5	See "Status Bit Definitions" below	Status bits
6	See "Fault Type Definitions" below	Fault type
7	0	
8	See "Scanning Module Faults" below	Scanning module faults
9	reserved	
A, etc...	I/O Slot status (<i>repeated for each I/O module</i>). May have the following values for a Bus Interface Unit application:	
	01 = empty	The configuration is installed, but there is nothing present in the slot even though that slot has been configured.
	02 = discordant	The configuration is installed, but the module in the slot does not match the configuration. May also indicate a module installed in an unconfigured slot.
	04 = operational	Configuration installed, correct module is present in slot, and it is fully functional.
	ff = fault (255 decimal)	Configuration is installed, correct module is present in slot, but it is not functional.

Status Bit Definitions




Fault Type Definitions



If the watchdog timer expires, the Bus Interface Unit goes to Idle mode and sets the Watchdog Expired bit in byte 8 (see below). This bit remains set until the next time the Bus Interface Unit is commanded to go to Ready or Run mode.

Scanning Module Fault Definitions



Chapter 4

Hand-held Programmer Functions

This chapter explains how to use a Hand-held Programmer with a FIP Bus Interface Unit:


- Using the Hand-held Programmer
 - HHP Displays
 - Menu Overview
 - Moving from Screen to Screen
- Displaying and Editing Configuration Data
 - Displaying the Bus Interface Unit Configuration
 - Configuring I/O Modules
 - Reading a Module Configuration
 - Configuring an Empty Slot
 - Configuring a Discrete Input Module
 - Configuring a Discrete Output Module
 - Configuring an Analog Input Module
 - Configuring an Analog Output Module
- Monitoring and Forcing I/O Data
 - Looking at I/O Data
 - Changing the Data Display Format: Binary, Hex, Decimal
 - Forcing and Unforcing Data
- Displaying and Clearing Faults
 - Displaying Faults
 - Clearing Faults

For Additional Information, Also See:

For additional information on basic Hand-held Programmer functions, please refer to the *Hand-held Programmer User's Manual* (GFK-0402).

Using the Hand-Held Programmer


Attach the Hand-held Programmer to the MONITOR connector on the BIU.



HHP Displays


The content of the HHP display screens varies according to the type of device it is connected to (for example, the screens for a FIP BIU are different from the screens for a Remote I/O Scanner).

This is the HHP's main menu when it is connected to a FIP Bus Interface Unit:



Menu Overview

The illustration below shows the primary Hand-held Programmer menus that are accessed from the FIP BIU main menu.



Moving from Screen to Screen

To move between displays, use the following keys:

- ➡ press the Right Arrow key to go “down.”
- ⬅ press the Left Arrow key to go “up.”
- ⬆ press the Up Arrow key to go up one branch.

Advancing past the last screen in a set returns you to the top.

Displaying and Editing Configuration Data

From the main menu, press the **2** key (Configuration). This menu appears:

```
1 FIP Config
2 Module Config
```

From this menu, you can:

- Press the **1** key to display, but not change, the FIP Bus Interface Unit configuration.
- Press the **2** key to enter, display, and edit I/O module configurations.

Displaying the Bus Interface Unit Configuration

When you press the number **1** key from the Configuration menu, the first BIU configuration display screen appears.

The first screen shows the FIP Station ID (14 in this example).

```
FIP ID
14
```

Displaying the FIP Protocol Type

Press the Right Arrow or Left Arrow key to see whether the BIU is configured for (Cegelec) FIP or WorldFIP protocol.

```
FIP TYPE
WORLD FIP
```

Displaying the Software Version of the BIU


Press the Right Arrow or Left Arrow key to see the BIU software version.

```
Software Version
*.*
```

Configuring I/O Modules

When you press the **2** key from the Configuration menu, the first module configuration screen appears.

At first, the module configuration screen looks like this:




The **Rack Number** is always 0.

The **Slot Number** refers to the location of the module in the station, relative to the Bus Interface Unit. See the illustration at left.

From this screen, you can:

- Display other modules using the Right Arrow and Left Arrow key.
- Delete the currently-displayed module by pressing the **DEL** key.
- Configure the currently-displayed module by pressing the **ENT** key.

To edit the module's configuration, press F4 (zoom). Refer to the module configuration instructions on the following pages for more information.



Reading a Module Configuration

If there is an unconfigured module present in the slot, press the **READ** key to read its configuration. You can edit this configuration as described on the following pages.

Configuring an Empty Slot

If there is no module present in the slot, the screen displays:

R0:S1 EMPTY

If you want to enter a configuration, press the **INS** key. This screen will appear:

**R0:S1 I/O Type ?
Generic I/O**

1. Press the +/- key to select either Generic I/O or Special I/O (see the list below). Then press the **ENT** key..

**R0:S1 I/O Type ?
Special I/O**

2. The screen prompts: **R0:S1 Mod Type ?** Use the +/- key to go through the module names listed below.

GenericI/O	Modules	SpecialI/O	Modules
DiscreteInput4/8		Analog 8 Current Input	IC670ALG230
All 16-point Discrete Input modules	IC670MDL640	Analog 4 Current Output	IC670ALG320
Discrete Input 32		Analog 8 Volt Differential Input	
DiscreteOutput4/8		Analog 4 Voltage Output	
All 16-point Discrete Output modules	IC670MDL740	Redundant 4 Discrete Output	
Discrete Output 32		120 VAC 8 Input/Output 2Amp	
Analog Input 4 Channel		120 VAC 4 Input/Output Isolated	
Analog Input 8 Channel		24VDC 8 Source/Sink	
Analog Output 4 Channel		24 VDC 8 Tristate	
Analog Output 8 Channel			

3. When the correct module name appears, press the **ENT** key. Complete the module configuration as described on the following pages.
 - to configure a Discrete Input Module, see page 4-8.
 - to configure a Discrete Output Module, see page 4-9.
 - to configure an Analog Input Module, see page 4-10.
 - to configure an Analog Output Module, see page 4-14.

Configuring a Discrete Input Module

A discrete input module has two configurable parameters:

- Fault Reporting
- Selection of either Hold Last State or Default to Zero for all the module's inputs.

Report Faults

If you press the **ENT** key from a discrete module screen, the following configuration screen appears:

```
S1 Report Faults
NO
```

The first line shows the module's slot number (**S**lot **1** above) and the first configuration parameter, Fault Reporting. This parameter determines whether or not the Bus Interface Unit will report faults from the module to the host.

1. Select Y if the Bus Interface Unit should report module faults to the host. Select N if it should not. Use the +/- key if you want to change the selection.
2. Use the **ENT** key to save the selection and go on to the next item.

Default Inputs or Hold Last State

If you press the **ENT** key from the Report Faults screen, the following configuration screen appears:

```
S1 Hld Lst State
NO
```

This parameter determines what type of data the Bus Interface Unit should provide to the host if it stops receiving actual input data from the module.

1. Select YES if the Bus Interface Unit should hold inputs in their last states and supply that data to the host.
Select NO if the Bus Interface Unit should default all the module's inputs to 0 and supply that data to the host instead.
2. Use the **ENT** key to save the selection.

Configuring a Discrete Output Module

A discrete output module has three configurable parameters:

- Selection of either Hold Last State or Default for all the module's outputs.
- Selection of either 0 or 1 as the default state for each output (used only if Hold Last State is set to NO).
- Fault Reporting

Default Outputs or Hold Last State

The selection determines what type of data the Bus Interface Unit will provide to the module if it stops receiving actual output data from the host.

```
S2 Hld Lst State
NO
```

1. Use the +/- key if you want to change the selection.

Select YES if the Bus Interface Unit should hold outputs in their last states and supply that data to the module.

Select NO if the Bus Interface Unit should default all the module's outputs and supply that data to the module instead.

2. Use the ENT key to save the selection.

If Hold Last State is set to NO, the following screen appears:

```
S1 Out Def Pt 01
_0010000010010101
```

Number of the point at the cursor location

3. On this screen, select a default state (1 or 0) for each output.
4. Use the ENT key to save the entries.

Report Faults

On the next screen, configure whether or not the Bus Interface Unit will report faults from this module to the host.

```
S2 Report Faults
NO
```

1. If you want to change the current selection, press the +/- key.
2. Use the ENT key to save the selection and go on to the next item.

Configuring an Analog Input Module

An analog input module has these configurable parameters:

- Default inputs or hold inputs in their last values
- Fault Reporting
- Channel active
- Input current/voltage range
- Input scaling
- Alarm thresholds

Default Inputs or Hold Last Values

First, configure what type of data the Bus Interface Unit should provide to the host if it stops receiving actual input data from the module.

```

S3 Hld Lst State
NO

```

1. Use the +/- key if you want to change the selection.
 Select YES if the Bus Interface Unit should hold inputs in their last states and supply that data to the host.
 Select NO if the Bus Interface Unit should default all the module's inputs to 0 and supply that data to the host instead.
2. Use the ENT key to save the entry and go on to the next configuration step.

Fault Reporting

The Bus Interface Unit can report faults for each channel to the host. If fault reporting is enabled for a channel, the Bus Interface Unit sends a message to the host CPU if any fault occurs on that channel. If fault reporting is disabled, the Bus Interface Unit does not send fault reports for the channel to the host CPU.

Regardless of whether fault *reporting* is enabled, the Bus Interface Unit detects faults on the circuit and takes appropriate action. If a fault occurs, the fault condition must be corrected for proper operation of the I/O module.

```

S3 Faults Ch 01
NNYYYYYY


```

Number of the channel
at the cursor location

1. For each channel, select Y if the Bus Interface Unit should report module faults to the host for that channel. Select N if it should not. Use the +/- key if you want to change the selection.
2. Use the Left Arrow and Right Arrow keys to select channels.
3. Use the ENT key to save the selections on this screen and go on to the next item.

Channel Active

If a channel is not wired, or if a channel is wired but should not report diagnostics, that channel can be configured as inactive.




1. For each channel, select Y if the channel should be active. Select N if it should not.
2. Use the Left Arrow and Right Arrow keys to select channels.
3. Use the ENT key to save the selections on this screen and go on to the next item.

Input Current/Voltage Ranges

Select a voltage or current range for each channel to correspond to the signal level of the input device. Note that Current Source Analog Input Module (IC670ALG230) and Current Source Analog Output Module (IC670ALG320) can only be set for 0 to 20mA or 4 to 20mA.

- 0 to 20mA
- 4 to 20 mA
- 0 to 10 volts DC
- 10 volts DC to +10 volts DC



1. For each channel, use the +/- key to select a range.
2. Repeat this step for each of the eight channels, using the Left Arrow and Right Arrow keys to select channels.
3. Use the ENT key to save the selections on this screen and go on to the next item.

Note


Range Selection is a setup parameter; it is not ordinarily changed while the module is operating.

Input Scaling

Based on the actual analog input signal level for a channel, the analog input module reports a value from decimal 0 to 4095 to the Bus Interface Unit. This value is then converted to internal units. The Bus Interface Unit can convert this internal value to a value that is more meaningful to the application by using the “scaling values” configured on this screen.

For each channel, two sets of values are configured: high and low internal values and the actual high and low engineering unit values they represent. Based on these two pairs of values, the Bus Interface Unit will be able to scale values for all other input levels.

See the *Bus Controller User’s Manual* for information on finding appropriate scaling values for your application. If you don’t have scaling values ready, you can continue to the next screen now, and configure scaling at another time. The Bus Interface Unit will use default scaling values of 1:1 if no scaling values are entered.



1. For EACH channel in turn, enter scaling values in this order:
 - Low scaling value (“eng lo”)
 - High scaling value (“eng hi”)
 - Low digital value (“int lo”)
 - High digital value (“int hi”)
2. If you press the Right Arrow key, the display goes from value to value in sequence. If you press the Left Arrow key, the display goes to the first value for the previous channel.
3. Use the HHP keypad to enter values. To enter a negative value, first enter the numbers, then press the - key.
4. Use the ENT key to save the selections on this screen and go to the next item.

Alarm Thresholds

Each input channel can have two Alarm Thresholds, one for a low engineering units (scaled) value and one for a high value.

Maximum values are " 32,767. The high threshold should be greater than the low threshold. Threshold limits are based on circuit scaling. If scaling is changed, review and readjust the Alarm Thresholds if necessary.

Alarm Thresholds can be set anywhere over the dynamic range of the signal. Typically, they are set at levels beyond which the input should not operate or levels beyond which alternate processing is required. They can also be set beyond the dynamic range of the signal, ensuring that they will never be activated. See the examples below.

1. For EACH channel in turn, first, enter a low alarm value:

```
S3 Alarm Ch 01
00000 low
```

Number of the channel you are now configuring

2. Press the ENT key.
3. Then enter a high alarm value:

```
S3 Alarm Ch 01
00000 high
```

4. Use the Arrow keys to select channels.
5. Press the ENT key to save the selection. Press the Right Arrow key to return to the original slot configuration screen.

Example 1:

A circuit is expected to report engineering unit values of -20 ft/sec (-6 m/sec) to +180 ft/sec (+50 m/sec). The high alarm is set at 150 ft/sec (+40 m/sec) and the low alarm at -25ft/sec(-7.5m/sec).

If an input reached its high alarm, a new threshold could be set. This could generate a high-high alarm or an alarm-cleared threshold.

Example 2:

An Alarm Threshold is set at 150 ft/sec. Upon receiving an alarm message, the CPU changes the Alarm Threshold to 165 ft/sec by using a Write Configuration command and sends the appropriate Clear Circuit Fault command. No alarm message is sent upon changing the threshold unless the speed is greater than 165 ft/sec. If the speed is only 157 ft/sec but increasing, a second message would be sent at 165 ft/sec. Since these two diagnostic messages are the same, it would be necessary for the program to keep track of the level of the Alarm Thresholds and recognize this as a higher alarm than that received initially. At the same time, it could move the low alarm to 140 ft/sec and use this level to detect the end of the high alarm conditions.

Configuring an Analog Output Module

An analog output module has these configurable parameters:

- Default outputs or hold outputs in their last values
- Fault Reporting
- Channel active
- Output current/voltage range
- Output scaling

Default Outputs or Hold Last Values

First, configure what type of data the Bus Interface Unit should provide to the module if it stops receiving actual output data from the host.

```
S4 Hld Lst State
NO
```

1. Select YES if the Bus Interface Unit should hold outputs in their last states and supply that data to the module.


Select NO if the Bus Interface Unit should default all the module's outputs and supply that data to the module instead.

2. Press ENT to save the selection.

Fault Reporting

The Bus Interface Unit can report faults for each channel to the host. If fault reporting is enabled for a channel, the Bus Interface Unit sends a message to the host CPU if any fault occurs on that channel. If fault reporting is disabled, the Bus Interface Unit does not send fault reports for the channel to the host CPU.


Regardless of whether fault *reporting* is enabled, the Bus Interface Unit detects faults on the circuit and takes appropriate action. If a fault occurs, the fault condition must be corrected for proper operation of the I/O module.



1. Use the +/- key to select Y or N for each channel. Select Y if the Bus Interface Unit should report module faults to the host for that channel. Select N if it should not.
2. Use the Arrow keys to select channels. If Hold Last State is set to NO, pressing the Left Arrow key from the first channel displays the Output Default screen.

Channel Active

If a channel is not wired, or if a channel is wired but should not report diagnostics, that channel can be configured as inactive.




1. For each channel, select Y if the channel should be active. Select N if it should not.
2. Use the Left Arrow and Right Arrow keys to select channels.
3. Use the ENT key to save the selections on this screen and go on to the next item.

Output Current/Voltage Ranges

Select the voltage or current range for each channel to correspond to the signal level of the output device. Note that Current Source Analog Output Module (IC670ALG320) can only be set for 0 to 20mA or 4 to 20mA.

- 0 to 20mA
- 4 to 20 mA
- 0 to 10 volts DC
- 10 volts DC to +10 volts DC



1. For each channel, use the +/- key to select a range.
2. Repeat this step for each of the eight channels, using the Left Arrow and Right Arrow keys to select channels.
3. Use the ENT key to save the selections on this screen and go on to the next item.

Note


Range Selection is a setup parameter; it is not ordinarily changed while the module is operating.

Output Scaling

While the actual values received from the application program may represent various types of engineering units, the Bus Interface Unit reports values from decimal 0 to 4095 to an analog output module. The BIU converts the application data into internal units using "scaling values". These internal values are then converted to counts and sent to the output channels.

For each channel, two sets of values are configured: high and low internal values and the actual high and low engineering units values they represent. Based on these two pairs of values, the Bus Interface Unit will be able to scale values for all other output levels.

See the *FIP Bus Controller User's Manual* for information on finding appropriate scaling values for your application. If you don't have scaling values ready, you can continue to the next screen now and configure scaling at another time. The Bus Interface Unit will use default scaling values of 1:1 if no scaling values are entered.



1. For EACH channel in turn, enter scaling values in this order:

- Low scaling value ("eng lo")
- High scaling value ("eng hi")
- Low digital value ("int lo")
- High digital value ("int hi")


2. If you press the Right Arrow key, the display goes from value to value in sequence. If you press the Left Arrow key, the display goes to the first value for the previous channel.
3. Use the HHP keypad to enter values. To enter a negative value, first enter the numbers, then press the +/- key.
4. Use the ENT key to save the selections on this screen and go to the next item.

Note

Range Selection is a setup parameter; it is not ordinarily changed while the module is operating.

Monitoring and Forcing I/O Data

From the main menu, press the **1** key (Monitor I/O). This menu appears:



From this menu, you can:


- Press the **1** key to display and force I/O data.
- Press the **2** key to display fault information.

Looking at I/O Data

When you press **1** from the Monitor I/O menu, the HHP displays I/O data starting with the first configured discrete input (I) data. Press the Right Arrow key to display more data in this sequence:

- All discrete inputs (I)
- All discrete outputs (Q)
- All analog inputs (AI)
- All analog outputs (AQ)

The illustration below shows the format of the data display screens.



Changing the Data Display Format: Binary, Hex, Decimal

To change the data format, press the **DEC/HEX** key.

I00001	0	B	Binary format
I00001	007E	H	Hexadecimal format
I00001	+00216D		Decimal format

Forcing and Unforcing Data

To force data with the Hand-held Programmer:

1. Place the HHP in the correct display format:
 - A. Binary for discrete data.
 - B. Hex or decimal for analog data.
2. Select the data to be forced or unforced. For example:

```
I00001  0  B
```

3. Press the **ENT** key. The screen displays:

```
1 Force
2 Unforce
```

4. To force the point, press the **1** key. A cursor appears on the screen, indicating that the HHP is ready for you to enter the intended force value from the keypad.

```
I00001  0  B
_
```

Enter the force value and press the **ENT** key. An asterisk before the value indicates that it is forced.


```
I00001  *1  B
```

The HHP screen also blinks when displaying validators that correspond to a selected range of forced data.

5. To remove the force, press the **ENT** key to display the Force menu. Press the **2** key.

Displaying and Clearing Faults

The Bus Interface Unit reads faults from I/O modules. It can store up to 32 uncleared faults (both BIU and module faults) in its internal fault table. As faults occur, the first 16 are saved in the internal table. They stay there until the faults are cleared; none of these 16 faults is lost if the table overflows. However, for faults 17 through 32, the internal fault table operates as a First-In-First-Out stack. When fault 33 occurs, fault 17 is dropped from the table.



Displaying Faults

1. From the main menu, press the **1** key (Monitor I/O). This menu appears:

```
1 Monitor I/O
2 Faults
```

2. From this menu, press the **2** key to display the Faults menu.

```
1 First 16 Flts
2 Last 16 Flts
```

3. Press the **1** key or the **2** key to display a set of 16 faults (one fault at a time). For example:

```
Slot #1 Fault#01
CONFIG MISMATCH
```

Clearing Faults

Pressing the **CLR** key from the Hand-held Programmer clears all the faults that are presently in the BIU's internal fault tables. Any faults that still exist are reported again.

Clearing faults from the Hand-held Programmer does not clear faults at the host PLC. To keep the entire system in step and up-to-date, fault clearing should be performed from the host PLC.

A

- Address selection, DIP switches, 2-7
- Alarm thresholds, configuring for analog input module, 4-13
- Analog Input Module, configuration steps, 4-10
- Analog inputs, 3-9
 - transmitted on bus, 3-10
- Analog Output Module, configuration steps, 4-7 , 4-14
- Analog outputs, 3-11
 - transmitted on bus, 3-11
- Auxiliary I/O Terminal Block, 1-3

B

- Binary data, 4-18
- Bus, connecting to Bus Interface Unit, 2-12
- Bus Interface Unit
 - description, 1-6
 - dimensions, 1-6
 - functional specifications, 1-10
 - fuse, 1-6
 - installing on terminal block, 2-8
 - introduction, 1-3
 - power supply, 1-7
 - removing from terminal block, 2-3
 - terminal block, 1-3 , 1-9

C

- Cables, between terminal blocks, 1-9
 - installing, 2-6
- Channel active, configuring for analog input module, 4-11 , 4-16
- Clearances required, 2-4
- Communications
 - effect on operating mode, 3-1
 - in Run mode, 3-3
- Communications Variables, 3-6 , 3-7 , 3-10 , 3-11
- Compatibility among devices, 1-11
- COMVs, 3-6 , 3-7 , 3-10 , 3-11 , 3-13

- Configuration
 - changes not permitted in Run mode, 3-3
 - selectable features, 1-12
- Control wiring, 2-9
- Current/voltage range
 - configuring for analog input module, 4-11
 - configuring for analog output module, 4-16

D

- Decimal data, 4-18
- Diagnostics, 3-13
- DIN rail
 - installing Terminal Block, 2-5
 - mounting, 2-4
 - removing Terminal Block, 2-15
- DIP switches
 - board address selection, 2-7
 - FIP protocol selection, 2-7
- Discrete Input Module, configuration steps, 4-8
- Discrete inputs, transmitted on bus, 3-6
- Discrete Output Module, configuration steps, 4-9
- Discrete outputs, transmitted on bus, 3-7

E

- Enclosures, 1-4
- Equipment required with Field Control, 1-11
- ESD protection, 2-2

F

- Fault Reporting
 - configuring for analog input module, 4-10
 - configuring for analog output module, 4-7 , 4-14
 - configuring for discrete input module, 4-8
 - configuring for discrete output module, 4-9
- Faults, displaying and clearing, 4-20

Features, 1-1
FIP protocol, selecting type with DIP switches, 2-7
Force retention, 3-2
Forcing data, 4-19
 analog inputs, 3-9
 discrete inputs, 3-5
 discrete outputs, 3-8
Fuse, Bus Interface Unit, 1-6 , 2-14

G

Grounding
 Bus Interface Unit, 2-11
 system, 2-10

H

Hand-held Programmer
 change data format, binary, hex, decimal, 4-18
 connection to Bus Interface Unit, 4-2
 connector on Bus Interface Unit, 1-6
Menus, 4-3
 screen format for displaying/forcing data, 4-18
 use not permitted in Run mode, 3-3
 using to display data, 3-4
 using with Remote I/O Scanner, 1-11
Hex data, 4-18
Humidity specification, 1-5

I

I/O data
 analog inputs, 3-9
 analog outputs, 3-11
 discrete inputs, 3-5
 discrete outputs, 3-7
 types and quantities, 3-4
I/O modules
 configure type, 4-7
 introduction, 1-3
 locations for, 1-4
I/O Scanning
 in Idle mode, 3-2
 in Ready mode, 3-2
I/O Terminal Blocks, introduction, 1-3

Input data, 3-9
Input module, analog, configuration steps, 4-7 , 4-10 , 4-14
Input module, discrete, configuration steps, 4-8
Input power requirements, 1-8
Inputs, default or hold last state
 configuring for analog input module, 4-10
 configuring for discrete input module, 4-8

L

LEDs, 2-13
Locations for I/O modules, 1-4
Logic power, 1-7
Logicmaster 90-70, software version required, 1-11

M

Modules
 I/O modules, 1-3
 I/O Terminal Blocks, 1-3
 types of, 1-2
Mounting clearances, 2-4
Mounting positions, 1-4
Mounting screws, 2-4

N

Noise
 preventing, 2-9
 providing transient protection, 2-11
 specifications, 1-5

O

Operating modes, 3-1
 idle, 3-1 , 3-2
 ready, 3-1 , 3-2
 run, 3-1 , 3-3
Output defaults, configuring for discrete output module, 4-9
Output module, discrete, configuration steps, 4-9
Outputs
 default or hold last state
 configuring for analog output module, 4-14

configuring for discrete output module, 4-9
off in idle mode, 3-2

P

Panel mounting, 2-4
Pin assignments for the bus connectors, 2-12
Power
 specifications, 1-10
 to Bus Interface Unit, 2-11
 wiring, general information, 2-9
Power Supply
 input power requirements, 1-8
 specifications, 1-10
 timing, 1-7
Preinstallation check, 2-2

R

Rack number, 4-6
Ready mode, 3-2
 entered after receiving system configuration, 3-2

S

Scaling values
 configuring for analog input module, 4-12
 configuring for analog output module, 4-17
Series 90-70 PLC, CPU version required for Field Control, 1-11

Signal wiring, 2-9
Slot number, configuration, 4-6
Specifications, 1-10
 See also individual I/O module data-sheets
 electrical, 1-10
 environmental, 1-5
 noise, 1-5
 temperature, 1-5
 vibration, 1-5
Standards, 1-5
Status data format, 3-14

T

Temperature specifications, 1-5
Terminal Block
 installing on DIN rail, 2-5
 removing from DIN rail, 2-15

V

Validator data, 3-4
 analog inputs, 3-9
 discrete inputs, 3-5
 discrete outputs, 3-7
 generated and observed in Run mode, 3-3
 set to invalid in idle mode, 3-2
Vibration specification, 1-5

W

Wiring guidelines, 2-9