



GE Fanuc Automation

Programmable Control Products



GE Fanuc Automation

*P.O. Box 8106
Charlottesville, VA 22906*

GFZ-0087

Series 90TM-70 GENIUSTM Bus Controller and GENIUS I/O System

Troubleshooting Guide



GE Fanuc Automation

Programmable Control Products

Series 90TM-70 GENIUSTM Bus Controller and GENIUS I/O System

Troubleshooting Guide

GFZ-0087

January 1994

Notice

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained in this document does not purport to cover all details or variations in hardware and software, nor to provide for every contingency in connection with installation, operation and maintenance. This document may describe features not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness or usefulness of the information contained in this document. No warranties of merchantability of fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	CIMSTAR	Helpmate
PROMACRO	Series Six	CIMPLICITY
GEnet	Logicmaster	Series One
Series 90	CIMPLICITY 90-ADS	Genius
Modelmaster	Series Three	VuMaster
ProLoop	CIMPLICITY PowerTRAC	Series Five
Workmaster	Genius Power TRAC	

© Copyright 1993 GE Fanuc Automation North America, Inc.

All Rights Reserved.

Safety Considerations

General Warnings When Troubleshooting

Stand clear of controlled equipment when power is applied. If the problem is intermittent, sudden unexpected machine motion could occur, causing injury. Also reference NFPA 70E Part II for additional guidelines for safety practices.

Never reach into a machine to operate a switch since unexpected motion could occur, causing injury.

Remove all electrical power at the Main Power Disconnect to ensure total power removal.

Always remove power before inserting or removing modules, or before connecting I/O cabling.

Preface

This guide describes a logical sequence for troubleshooting your Series 90–70 Genius Bus Controller, communications between the 90–70 GBC and attached Genius blocks, and the installed Genius cable plant. The Series 90–70 PLC is a member of the Series 90™ family of programmable logic controllers from GE Fanuc Automation.

Revisions to this Troubleshooting Guide

This is the first release of this Troubleshooting Guide.

Related Publications

Series 90™–70 Programmable Controller Installation Manual (GFK–0262).

Logicmaster™ 90–70 Programming Software User's Manual (GFK–0263)

Series 90™–70 Programmable Controller Reference Manual (GFK–0265)

Series 90™–70 PLC Genius™ Bus Controller User's Manual (GFK–0398)

Genius™ I/O System and Communications User's Manual (GEK–90486–1)

Genius™ I/O Discrete and Analog Blocks User's Manual (GEK–90486–2)

Genius™ I/O PCIM User's Manual (GFK–0074)

Genius™ I/O PowerTRAC Block User's Manual (GFK–0450)

Genius™ I/O High Speed Counter User's Manual (GFK–0415D)

Series 90™–30 Genius Communications Module User's Manual (GFK–0412)

Series 90™–30 Enhanced Genius Communications Module User's Manual (GFK–0695)

We Welcome Your Comments and Suggestions

At GE Fanuc Automation, we strive to produce quality technical documentation. After you have used this troubleshooting guide, please take a few moments to write us with your comments and suggestions. Our address is: Manager Technical Publications, GE Fanuc Automation, PO Box 8106, Charlottesville, VA 22906

Drake C. Fink
Sr. Staff Systems Engineer

Using this Guide

This guide directs you to use the Genius Hand Held Monitor (HHM) and the Series 90–70 Fault Tables to troubleshoot your Series 90–70 Genius Bus Controller and the attached Genius bus system. If you are unfamiliar with the operation of the HHM, refer to GFK–0121, *Genius Hand Held Monitor Data Sheet* and GEK–09486–2, *Genius I/O Discrete and Analog Blocks User's Manual*. For information on using the HHM with the PowerTRAC and High Speed Counter Blocks, refer to the manuals for those devices: GFK–0405, *Genius PowerTRAC Block* and GFK–0415, *Genius I/O High Speed Counter*. If you are unfamiliar with accessing and interpreting the Series 90–70 I/O Fault Table, refer to GFK–0263, *Logicmaster 90–70 Programming Software User's Manual* and GFK–0265, *Series 90–70 Programmable Controller Reference Manual*.

Sometimes solving one problem reveals another problem. Therefore, when this guide concludes that a problem seemingly is resolved, you are directed to reverify the condition of the system. When you resolve a problem with a Genius device, also verify that the Genius Bus Controller functions properly. Similarly, when you resolve a problem with the Genius Bus Controller, also verify that all Genius devices are functioning as you expect. **This Guide does not apply to troubleshooting Genius Modular Redundancy systems.**

Abbreviations used in this Guide include:

BTM	...	Bus Transmitter Module (IC697BEM713)
BRM	...	Bus Receiver Module (IC697BEM711)
GBC	...	Genius Bus Controller (IC697BEM731)
HHM	...	Genius Hand Held Monitor
LM90	...	Logicmaster 90–70
SBA	...	Serial Bus Address; same as device number

The next page describes the symbols used in this *Troubleshooting Guide*.

SYMBOLS USED IN THIS GUIDE




BEGIN AT THIS SYMBOL
ON THE FIRST CHART.




FOLLOW THE PATH WITH
THE CORRECT ANSWER IN
THE DIRECTION OF THE
ARROW


SYMBOLS USED THROUGHOUT THE GUIDE
ARE GEOMETRICALLY CODED




A DIAMOND ASKS A
QUESTION



A RECTANGLE TELLS
YOU TO DO SOMETHING



A NUMBERED BUBBLE WITH
AN ARROW INTO THE BUBBLE
INDICATES THAT THE
PROCEDURE IS CONTINUED
AT A CORRESPONDINGLY
NUMBERED BUBBLE ON THE
INDICATED PAGE NUMBER.





A NUMBERED BUBBLE WITH
AN ARROW OUT OF THE
BUBBLE INDICATES THE
START OF A PROCEDURE ON
THAT PAGE.


USING


GENIUS BLOCK
TROUBLESHOOTING


(Refer to the Preface for
information on safety
considerations, related
publications and the
symbols used in this
guide.)





















* CHECK FOR FORCES WITH LM90 AS WELL AS WITH THE HHM.











GBC TROUBLESHOOTING














GBC PASSED
POWER-UP
DIAGNOSTICS







Additional Troubleshooting Tips

- If the PLC is in *RUN/ENABLED* mode, verify all blocks are powered on. Verify all blocks are communicating with the PLC CPU (both LEDs on). If a block is not communicating, the I/O Fault Table will show a Loss of Block fault for that block.
- Verify bus is connected to all devices and to the GBC. I/O Fault Table will have a Loss of Block fault for all blocks downstream from a bus break.
- Verify with the Hand Held Monitor that all blocks can be monitored from the bus connector on the 90–70 Genius Bus Controller.
- Verify the configuration of the block in LM90 Configuration is the same as the block's configuration with the Hand Held Monitor (i.e., Grouped vs. Input-only, etc.) The PLC Fault Table will show a "System Configuration Mismatch" (I/O type mismatch, model number mismatch, BCD length mismatch, reference address mismatch).
- Verify baud rate of GBC matches the configured baud rate of the blocks. If you change the GBC baud rate and store configuration to the PLC, the GBC must be power cycled for the baud rate to be effective. The I/O Fault Table may have Loss of Block fault if baud rates differ.
- If the situation persists, call your distributor or the GE Fanuc Hotline for assistance.

Notes and Precautions

1. Supply (input) voltage power tolerances for Genius blocks varies with the type of block (Analog, Digital) and type of voltage (AC, DC). Refer to the data sheet for an individual block for supply voltage tolerances.
2. For Resistive Temperature Detector (RTD), Thermocouple (TC) and Current Source Analog (CSA) blocks *only*, Unit OK LED off and I/O Enabled LED blinking indicates an electrical assembly/terminal assembly mismatch. For these same blocks, Unit OK off and I/O Enabled LED off or blinking indicates the block is faulty or there is no power to the block.
3. The Genius bus must be terminated with a resistor at each end. No resistor is permitted at any device which is in the middle of the bus, including Genius Bus Controllers. The resistor must match the impedance of the cable. Refer to the cable manufacturer's data sheet for cable impedance. Bus connections must be secure at each device. Shield In and Shield Out connections must be properly paired: from Shield Out on one device to Shield In on the next device on the bus. The cable must have no breaks. Refer to the Field Service note "Genius Cable Plant Troubleshooting Tips" for additional information.
4. Unit OK and I/O Enabled LEDs on a block may blink synchronously when the block is being configured by the Hand Held Monitor. In this case, the synchronous blinking is not a fault and may be ignored.
5. When the serial bus address (SBA, also called device number) is being checked, and you have reason to suspect that the SBA is duplicated in another device on the bus, the device being checked must be powered up and disconnected from the rest of the bus while the check is made.
6. When a circuit fault occurs on a block, the I/O enabled LED blinks. You must correct the circuit fault first, then clear the fault. The block latches the circuit fault indication when it occurs.
7. **CAUTION:** The overrides may be there for a reason. Check before removing them.

Troubleshooting Matrix

The following table shows the various states of the Unit OK and I/O Enabled LEDs on a Genius block, and the meaning of those states. This matrix and other block troubleshooting information is in Chapter 17, I/O Block Troubleshooting of GEK-90486-2 *Genius I/O Discrete & Analog Blocks User's Manual Volume 2*.

UNIT OK	I/O ENABLED	MEANING
ON	ON	Block functioning; CPU communicating
ON	OFF	Block functioning, No CPU communications for 3 bus scans
ON	Blinking	Block functioning, Circuit forced
Blinking	ON	Circuit fault, CPU communicating
Blinking	OFF	Circuit fault, No CPU communications for 3 bus scans
Alternate blinking		Circuit fault, Circuit forced
Synchronous blinking		No CPU communications; serial bus address conflict
OFF	Don't care or OFF	No power to block or block faulty. (For RTD, Thermocouple, and Current-source analog blocks, I/O enabled LED is off.
OFF	Blinking	For RTD, Thermocouple, and Current-source analog blocks, this indicates an Electronics assembly/Terminal assembly mismatch.

The following table shows the various states of the Module OK and Channel 1 (CH1) OK LEDs on a Series 90-70 Genius Bus Controller and the meaning of those states. A bus controller's two LEDs indicate its current operating condition. After startup, both of these LEDs are normally on.

MODULE OK	CHANNEL 1 OK	MEANING
ON	ON	GBC powered on; valid config loaded
ON	OFF	GBC powered on, no config loaded or slot misconfigured
ON	Blinking	Bus improperly wired or intermittent bus
OFF	ON	Defective GBC
OFF	OFF	No power to GBC or GBC reset by PLC CPU
OFF	Blinking	Defective GBC
Blinking	ON	Defective GBC
Blinking	OFF	GBC failed power up; blank slot between GBC and PLC CPU or I/O chain between expansion rack and main rack is broken
Blinking	Blinking	Serial bus address conflict

Genius Cable Plant Troubleshooting

One of the reasons for the popularity of the Genius I/O family is the advanced level of diagnostics available on a point-by-point basis. These diagnostics allow for quick identification of block-level hardware and I/O wiring problems, thus minimizing the overall mean time to repair (MTTR) for the control system. These diagnostics do not, however, assist in the troubleshooting of communications problems related to the cable plant, especially in newly installed systems. Here is a list of the troubleshooting tips that have proven to be the most valuable in starting up countless Genius systems around the world. If you have found others, we'd like to know about them!

Cable Installation There are a number of cable installation details that should be checked (twice!) if you are having trouble establishing reliable communications on your Genius cable plant :

Make sure that the Serial 1 and Serial 2 lines are connected to the correct terminals on each Genius block and/or controller. If even one block has these wires crossed there can be sporadic problems with loss of communications to one or more blocks.

Make sure that the Serial 1 and Serial 2 lines are not shorted to each other, to the shield lines, or to ground at any point in the system.

Make sure that the Shield In and Shield Out lines are properly connected throughout the system. It is very important that the Shield Out terminal of the first bus device is connected to the Shield In terminal of the second device and that the Shield Out terminal of the second device is connected to the Shield In terminal of the third device and so forth in a daisy-chain throughout the system. The first device's Shield In and the last device's Shield Out terminals should be left un-

connected. Incorrect wiring of the Shield In and Shield Out terminals can lead to ground loops and noise interference in your communications. Make sure that the Shield In and Shield Out lines are not shorting to each other where they are exposed at each connection point in the network. It is a good idea to insulate at least one if not both of the exposed shield wires with "spaghetti" tubing so that the critical Shield In and Shield Out isolation is maintained.

Check for any splices in the cable plant. Cable splices are NOT recommended because they can cause signal reflections and introduce noise into the system but if they are absolutely necessary then they should be made inside a grounded junction box using a high quality barrier-type terminal strip with screw connections. *Mixing of different cable types (or manufacturers) is NOT recommended even for cables with similar specifications.*

Check for violations of the minimum bend radius for your cable type. If the minimum bend radius specified is exceeded then the signal carrying conductors may not be correctly centered within the shield layer. This can cause signal impedance problems for communication systems like Genius that operate at higher frequencies. Sharp right angle bends should be avoided at all costs. The larger the bend radius, the better in terms of preventing communications problems.

Make sure that the overall cable length and baud rate are compatible with the cable type used. Check the table on page 2-2 of GFK-90486D-1 to see if the total cable length in your cable plant is less than the maximum specified for your chosen baud rate. It may be necessary to change cable types, baud rates, or cable length and routing in order to get your cable plant within acceptable guidelines. Be aware that reducing the baud rate can also limit the total number of devices permitted on the bus!

Genius Cable Plant Troubleshooting

Serial Bus Address Conflicts There can be one and only one device (block, controller, or Hand Held Monitor) on each bus assigned to each Serial Bus Address 0 to 31. If more than one device on the bus has the same Serial Bus Address then the BLOCK OK and I/O ENABLED LEDs on the affected block(s) will blink synchronously.

Block Grounding Each Genius block must have a secure and direct connection to ground. This ground must be made using one of the green ground screws on the side of the Terminal Strip. Note that it is NOT acceptable to daisy-chain the ground connection between multiple blocks since ground loops and noise can result.

Load Suppression Inductive loads such as solenoids and relays require suppression circuitry to prevent the RFI noise produced by the coils from affecting the Genius block driving that load. This suppression normally takes the form of flyback diodes for DC coils and RC snubbers for AC coils. The suppression devices should be installed at the coil (or as close as possible) and not at the Genius block output point in order to prevent the noise from being coupled into other unprotected wiring circuits that may be routed in parallel. Refer to Chapter 2 of GFK-90486C-2 for specific information on load suppression devices.

Genius Bus Device Baud Rates All devices on each Genius bus must have the same baud rate selected (38.4k, 76.8k, 153.6k STD or 153.6k EXT). Even one block or controller set for the wrong baud rate will lead to unpredictable communications. Every block, controller, and Hand Held Monitor connected to the Genius bus must be checked to verify that it is set for the desired baud rate.

Termination Resistors Termination resistors are critical for the correct operation of your Genius cable plant. These resistors are needed to absorb and eliminate any echoed or reflected signals that can be generated in a communications system operating at high frequencies like those used by Genius. Check to see that the correct termination resistors have been installed in the correct locations. There should be two (and only two!) termination resistors installed in the network with one located at each of the physical ends of the cable plant. It is not necessary to install a termination resistor at the bus controller if it is located in the middle of the cable plant.

The termination resistor value for your cable installation will be dependent on the cable type used. See the table on page 2-2 in GFK-90486D-1 for the exact resistor value. Note that these resistors should NOT be of the wirewound variety since this will introduce unwanted inductance into the system.

Be advised that the Series Six Genius Bus Controller and the Genius Personal Computer Interface Module (PCIM) each have built-in termination resistors that can be selected or disabled with jumpers. You need to make sure that these jumpers are set correctly for your installation – it is easy to forget about these and accidentally have a third termination resistor (or the wrong value resistor) in your network.

One common problem reported during installation is communication errors between the Hand Held Monitor and stand-alone blocks during the initial block configuration process. This occurs because there is no termination to the communications bus connecting the Hand Held Monitor and the block – believe it or not, the coiled HHM cable is long enough to require termination! Add a 75 Ohm resistor across the Serial 1 and Serial 2 terminals of the target block and the errors should disappear. Be sure and remove this resistor once you are done configuring the blocks to prevent over-termination of your cable plant.

Genius Cable Plant Troubleshooting

”Divide and Conquer” The troubleshooting tips detailed above presume that all Genius devices connected to the bus are functioning properly and that there is no defective or damaged cable anywhere in the system. While most Genius bus problems are resolved by one of the techniques listed above, there are times when further steps must be taken to find the cause of the communication difficulties. The simplest way to find defective blocks or cable is to use the ”divide and conquer” method. To do this, power down the system, disconnect the bus at some convenient point (ideally at the halfway point), and re-terminate the section with the bus controller. Turn the system power back on and observe the communications performance. If the problem persists on the shortened bus, split it and re-terminate again. Repeat this process until the shortened bus is finally operating correctly. Start adding back one block at a time until the problem appears again. The block and/or the cable section that is added when the problem re-appears should be investigated carefully. The ”problem” block is either defective, mis-wired, has a conflicting bus address or has an incorrect baud rate. It is also possible that there is a problem with the specific sections of cable connected to the block – there may be broken or shorted conductors, insulation problems, bad splices, minimum bend radius violations, or excessive noise sources along the cable path.